



SII Print Class Library for Android™ Application Programmer's Guide

Rev.06

[Products]

MP-B30 Series

MP-B30L Series

Seiko Instruments Inc.

Rev.01	January 2019
Rev.02	August 2019
Rev.03	March 2020
Rev.04	May 2020
Rev.05	March 2021
Rev.06	March 2022

Copyright © 2019-2022 by Seiko Instruments Inc.
All rights reserved.

Android™ is a trademark of Google LLC.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

Oracle and Java are registered trademarks of Oracle and/or its affiliates.

Other names may be trademarks of their respective owners.

Seiko Instruments Inc. (hereinafter referred to as "SII") has prepared this manual for use by SII personnel, licensees, and customers. The information contained herein is the property of SII and shall not be reproduced in whole or in part without the prior written approval of SII.

SII reserves the right to make changes without notice to the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical, arithmetic, or listing errors.

Introduction

This manual describes "SII Print Class Library for Android™" (hereinafter referred to as "SII print class library") provided by Seiko Instruments Inc. (hereinafter referred to as "SII").

Target printers

The printers supported by SII print class library are listed below.

Printers	Interface
MP-B30 Series	Bluetooth
	USB
	TCP/IP
MP-B30L Series	Bluetooth
	USB
	TCP/IP

Terms

The terms used in this manual are defined as below.

Terms	Description
Technical Reference	Technical References shown as follows: ·MP-B30 SERIES THERMAL PRINTER TECHNICAL REFERENCE ·MP-B30L SERIES THERMAL PRINTER TECHNICAL REFERENCE
Printer command	Command for controlling the printer described in "Technical Reference"
User's Guide	User's Guide shown as follows: ·MP-B30 SERIES THERMAL PRINTER USER'S GUIDE ·MP-B30L SERIES THERMAL PRINTER USER'S GUIDE

Table of Contents

Chapter 1	Product Overview	1-1
1.1	Functions Provided by SII Print Class Library	1-1
1.2	SII Print Class Library Overview.....	1-1
1.2.1	SII Print Class Library Configuration	1-1
1.2.2	Functions Provided by Library.....	1-2
Chapter 2	Product Specifications	2-1
2.1	Operating Environment	2-1
2.2	Printer Settings	2-2
2.2.1	MP-B30.....	2-2
2.2.2	MP-B30L.....	2-2
2.3	Precautions	2-3
Chapter 3	How to Use Library	3-1
3.1	Android Application Development Environment.....	3-1
3.2	Provided Files	3-2
3.3	Build Library into Android Studio Project	3-3
3.4	Use Developed Android Application on Android Device.....	3-5
3.5	Precautions	3-5
Chapter 4	Functions of Library	4-1
4.1	Standard Mode and Page Mode	4-1
4.1.1	Basic Operation.....	4-1
(1)	Standard mode.....	4-1
(2)	Page mode.....	4-2
4.1.2	Text Data Printing in Standard Mode.....	4-3
4.1.3	Mapping Position of Print Data in Page Mode.....	4-4
(1)	Print area of page mode.....	4-4
(2)	Print direction.....	4-4
(3)	Reference point.....	4-5
4.1.4	Print Data Process at Out of Print Area of Page Mode.....	4-6
4.2	API Reference.....	4-7
4.2.1	PrinterManager Class.....	4-8
(1)	Method List	4-8
①	Common method to standard mode and page mode.....	4-8
②	Dedicated method for standard mode	4-9
③	Dedicated method for page mode.....	4-10
(2)	Constant List	4-11
①	Printer model.....	4-11
②	Response type.....	4-11

③ Battery remaining capacity level	4-11
④ International character set	4-12
⑤ Codepage	4-12
⑥ Port type	4-13
⑦ Barcode or PDF417	4-13
(3) Enumerated Constant List	4-13
① Dithering (Dithering)	4-13
② Batch processing selection (TransactionFunction).....	4-13
③ Bold print (CharacterBold)	4-14
④ Underline (CharacterUnderline)	4-14
⑤ Reverse print (CharacterReverse)	4-14
⑥ Inversion print (CharacterInversion).....	4-14
⑦ Character font (CharacterFont)	4-14
⑧ Character scale (CharacterScale)	4-15
⑨ Alignment (PrintAlignment).....	4-15
⑩ Pending data output specifying (OutputPendingData)	4-16
⑪ Barcode symbol (BarcodeSymbol).....	4-16
⑫ Module size (ModuleSize).....	4-17
⑬ HRI character print position (HriPosition)	4-19
⑭ N:W ratio (NwRatio).....	4-19
⑮ Error correction level (ErrorCorrection)	4-19
⑯ PDF417 symbol (Pdf417Symbol).....	4-20
⑰ QR Code Model (QrModel).....	4-20
⑱ Data Matrix module (DataMatrixModule).....	4-20
⑲ MaxiCode Mode (MaxiCodeMode).....	4-21
⑳ Aztec Symbol (AztecSymbol)	4-21
㉑ Cutting method (CuttingMethod)	4-22
㉒ Form feed position (FeedPosition)	4-22
㉓ Print direction (Direction)	4-23
㉔ Line style (LineStyle)	4-24
(4) Method Details	4-25
① Common method to standard mode and page mode.....	4-25
PrinterManager Constructor	4-25
connect Start communicating with printer (Bluetooth)	4-25
connect Start communicating with printer (USB).....	4-26
connect Start communicating with printer (TCP/IP).....	4-26
disconnect Stop communicating with printer	4-27
setBarcodeScannerListener	
Start/End callback of barcode scanner	4-27
openDrawer Open cash drawer	4-27
buzzer Sound buzzer	4-27
externalBuzzer Sound external buzzer	4-27
getStatus Get printer status.....	4-28
setCallbackFunctionListener	
Start/End callback of printer status change.....	4-29
abort Abort waiting state of printer	4-29
registerLogo Register logo	4-30
unregisterLogo Delete registered logo	4-30

registerStyleSheet	Register style sheet.....	4-31
unregisterStyleSheet	Delete registered style sheet	4-31
resetPrinter	Reset printer	4-31
getPrinterResponse	Get various responses from printer.....	4-31
startDiscoveryPrinter	Start printer search (Bluetooth).....	4-33
startDiscoveryPrinter	Start printer search (USB)	4-33
startDiscoveryPrinter	Start printer search (TCP/IP)	4-33
cancelDiscoveryPrinter	Cancel printer search	4-34
getFoundPrinter	Get found printer information.....	4-34
getSendTimeout	Get send timeout period	4-34
setSendTimeout	Set send timeout period	4-35
getReceiveTimeout	Get receive timeout period	4-35
setReceiveTimeout	Set receive timeout period	4-35
getInternationalCharacter		
	Get international character set.....	4-35
setInternationalCharacter		
	Set international character set.....	4-36
getCodePage	Get codepage.....	4-36
setCodePage	Set codepage	4-36
getPrinterModel	Get printer model	4-37
getPortType	Get connecting port type	4-37
isConnect	Verify connection state with printer	4-37
getSocketKeepingTime	Get socket keeping time	4-37
setSocketKeepingTime	Set socket keeping time	4-37
getVersion	Get SDK version	4-38
controlTransaction	Start/End batch processing.....	4-38
② Dedicated method for standard mode		4-40
sendText	Send text data	4-40
sendTextEx	Send format specified text data	4-40
printBarcode	Print barcode.....	4-42
printPDF417	Print PDF417	4-44
printQRcode	Print QR Code.....	4-45
printDataMatrix	Print Data Matrix	4-46
printMaxiCode	Print MaxiCode	4-46
printGS1DataBarStacked		
	Print GS1 Databar Stacked	4-47
printGS1DataBarStackedOmnidirectional		
	Print GS1 Databar Stacked Omni-directional....	4-47
printGS1DataBarExpandedStacked		
	Print GS1 Databar Expanded Stacked.....	4-48
printAztecCode	Print Aztec Code	4-49
cutPaper	Cut paper	4-50
feedPosition	Paper form feed	4-50
sendBinary	Send binary data	4-50
sendDataFile	Send specified file.....	4-51
printLogo	Print logo.....	4-52
③ Dedicated method for page mode		4-53
enterPageMode	Start page mode.....	4-54

exitPageMode	End page mode.....	4-54
setPageModeArea	Specify print area of page mode.....	4-54
setPageModeDirection	Specify print direction of page mode	4-56
setPageModeLineSpacing	Specify line spacing of page mode	4-56
printPageMode	Print page mode.....	4-56
printPageModeText	Send text data of page mode	4-57
printPageModeTextEx	Send format specified text data of page mode .	4-57
printPageModeBarcode	Print barcode of page mode	4-58
printPageModePDF417	Print PDF417 of page mode.....	4-60
printPageModeQRcode	Print QR Code of page mode	4-62
printPageModeDataMatrix	Print Data Matrix of page mode.....	4-62
printPageModeMaxiCode	Print MaxiCode of page mode.....	4-63
printPageModeGS1DataBarStacked	Print GS1 Databar Stacked of page mode.....	4-64
printPageModeGS1DataBarStackedOmnidirectional	Print GS1 Databar Stacked Omni-directional of page mode.....	4-64
printPageModeGS1DataBarExpandedStacked	Print GS1 Databar Expanded Stacked of page mode.....	4-65
printPageModeAztecCode	Print Aztec Code of page mode.....	4-66
sendPageModeBinary	Send binary data of page mode.....	4-67
printPageModelImageFile	Draw Image file of page mode.....	4-67
printPageModeRectangle	Draw rectangle image of page mode	4-68
printPageModeLine	Print ruled line of page mode	4-69
printPageModeLogo	Print logo of page mode	4-71
4.2.2 PrinterEvent Class		4-72
(1) Method List		4-72
(2) End event constant.....		4-72
(3) Method Details		4-72
getEventType	Get end event	4-72
4.2.3 PrinterListener Interface		4-73
(1) Method List		4-73
(2) Method Details		4-73
finishEvent	End event of printer search	4-73
4.2.4 PrinterInfo Class.....		4-74
(1) Method List		4-74
(2) Method Details		4-74
getPrinterModelName	Get printer model name	4-74
getBluetoothAddress	Get Bluetooth address.....	4-74
getMacAddress	Get MAC address.....	4-74
getIPAddress	Get IP address	4-75

getIsBonded	Get pairing status	4-75
getDevicePath	Get device path	4-75
4.2.5 PrinterException Class		4-76
(1) Method List		4-76
(2) Constant List		4-76
① Error code		4-76
(3) Method Details		4-77
PrinterException	Constructor	4-77
getErrorCode	Get error codes	4-77
4.2.6 CallbackFunctionListener Interface		4-78
(1) Method List		4-78
(2) Method Details		4-78
onStatusChanged	Change event of printer status	4-78
4.2.7 BarcodeScannerListener Interface		4-79

Chapter 5	Sample Program	5-1
------------------	-----------------------	------------

5.1 Installation	5-1
5.2 Screen Layout	5-3
5.2.1 Main screen	5-3
5.2.2 [SETTINGS] screen	5-4
5.3 Precaution	5-4

Appendix A	Character Set	A-1
-------------------	----------------------	------------

A.1 Codepage Table (Character Code Table)	A-1
A.2 International Character Set	A-11

Chapter 1

Product Overview

This chapter describes the product overview of SII print class library.


1.1 Functions Provided by SII Print Class Library

The SII print class library including the library and the sample program provides the functions to use SII printer MP-B30/MP-B30L series (hereinafter referred to as "printer") in Android applications. Moreover, the SII print class library provides the library sample program in Android Studio project.

1.2 SII Print Class Library Overview

1.2.1 SII Print Class Library Configuration

The library and sample program in the SII print class library are indicated with dashed lines in the figure below.



1.2.2 Functions Provided by Library

By using the library, Android applications can easily send print data and printer commands to a printer through communication port (Bluetooth, USB or TCP/IP) on an Android device. Also, the applications can get the printer status.

The library provides the following functions:

- Connecting to / disconnecting from a printer
- Sending data to a printer (print data and/or printer commands*¹)
- Printing barcode and 2-dimensional barcode
- Sending a data file to a printer (print data and/or printer commands*¹)
- Getting the printer status
- Aborting the waiting state of a printer
- Getting various responses from a printer
- Bulk registration of print commands
- Registering a printer status call back function
- Searching the printer by Bluetooth or TCP/IP

*1: Commands that read responses from the printer are not supported. In order to read responses from the printer, use `getStatus` or `getPrinterResponse`.

(NOTE) MP-B30/MP-B30L does not support the APIs of Display or the barcode scanner.

Chapter 2

Product Specifications

This chapter describes the product specifications of the library.

2.1 Operating Environment

Operating environment for the library is shown in the following table.

Printer	Model		MP-B30/MP-B30L		
	Communication Interface		Bluetooth	USB	TCP/IP
Android Device	Communication Port		Bluetooth*1	USB*2	TCP/IP*3
	OS	Android 5.0 (API 21)	Supported	Supported	Supported
		Android 5.1 (API 22)			
		Android 6.0 (API 23)			
		Android 7.0 (API 24)			
		Android 7.1 (API 25)			
		Android 8.0 (API 26)			
		Android 8.1 (API 27)			
		Android 9.0 (API 28)			
		Android 10.0 (API 29)			
		Android 11.0 (API 30)			
		Android 12.0 (API 31)			
Supported Language		Japanese, English			

^{*1}: Bluetooth connection needs to be established by SPP (Serial Port Profile).

^{*2}: Android device needs to support USB host function.

^{*3}: The wireless LAN access point that the Android device is connected and the printer need to be connected to the same network.

2.2 Printer Settings

Set the memory switches of the printer to [Value] in the following table when using the library.
The memory switch of the printer can be set in the Android app "SII Printer Utility" on the Google Play.
See "User's Guide" for details about the memory switches and the factory default settings.

2.2.1 MP-B30

MS	Function	Value
1-1	Interface Selection (Interface)	1 : USB/Wireless ^{*1} 0 : USB ^{*2}
1-2	Mark Mode Selection (Mark Mode)	1 : Disable ^{*3}
1-6	Data Discard Selection When Error Occurs (Error Through)	0 : Enable
1-8	Data Discard Selection When Output Buffer Full Occurs (Response Data Discarding)	1 : Disable
2-2	Realtime Command Selection (Realtime Command)	0 : Enable
9-1	Automatic Status Response Selection (Auto Status Back)	0 : Enable
9-2	Initialized Response Selection (Init. Response)	0 : Enable

*1: Select "USB/Wireless" for Bluetooth connection or TCP/IP Connection.

*2: Select "USB" for USB connection.

*3: Select "Disable" when using cutPaper.

2.2.2 MP-B30L

MS	Function	Value
1-1	Interface Selection (Interface)	1 : USB/Wireless ^{*1} 0 : USB ^{*2}
1-2	Mark/Gap Mode Selection (Mark/Gap Mode)	1 : Disable ^{*3} 0 : Enable ^{*4}
1-3 to 1-5	Command System Selection (Command System)	000B : ESC/POS
1-6	Data Discard Selection When Error Occurs (Error Through)	0 : Enable
1-8	Data Discard Selection When Output Buffer Full Occurs (Response Data Discarding)	1 : Disable
2-2	Realtime Command Selection (Realtime Command)	0 : Enable
9-1	Automatic Status Response Selection (Auto Status Back)	0 : Enable
9-2	Initialized Response Selection (Init. Response)	0 : Enable

- *1: Select "USB/Wireless" for Bluetooth connection or TCP/IP Connection.
- *2: Select "USB" for USB connection.
- *3: Select "Disable" when using **cutPaper**.
- *4: Select "Enable" when using **feedPosition**.

2.3 Precautions

Communication ports cannot be shared with the printer driver and other libraries when using TCP/IP.

Chapter 3

How to Use Library

This chapter describes the development environment for Android application and how to use the library.

3.1 Android Application Development Environment

In order to develop Android applications, the following tools are required.
See each of the following URLs for more details.

- Android Studio
<https://developer.android.com/studio/index.html>
- USB driver for Windows (When developing in Windows environment)
<https://developer.android.com/studio/run/oem-usb.html>

The description in and after this chapter is on the premise that the environment where each tool is available is prepared.

3.2 Provided Files

The file configuration of the SII print class library is as follows.




Figure 3-1

The file format of the library is JAR. The file name of the library is SiiAndroidSDK.jar.

3.3 Build Library into Android Studio Project

Using the project of the sample program included in the SII print class library as an example, this section describes how to build the library into Android Studio project.

See "Chapter 5 Sample Program" for the sample program included in the SII print class library.

- (1) Select and right click the module (app) displayed in the Android Project view of Android Studio, and select [New] and [Directory] (Figure 3-2).
Enter "libs" in the folder name of the displayed dialog and click the [OK] button (Figure 3-3).




Figure 3-2




Figure 3-3

- (2) Copy the library file (SiiAndroidSDK.jar) into the folder (¥Sample¥app¥libs) created in step (1).

- (3) After adding the library, the view looks like Figure 3-4.




Figure 3-4

- (4) Add the following to the beginning of the main source file.
(Add to the beginning of MainActivity.java for the sample program.)

```
import com.seikoinstruments.sdk.thermalprinter.PrinterEvent;  
import com.seikoinstruments.sdk.thermalprinter.PrinterException;  
import com.seikoinstruments.sdk.thermalprinter.PrinterInfo;  
import com.seikoinstruments.sdk.thermalprinter.PrinterListener;  
import com.seikoinstruments.sdk.thermalprinter.PrinterManager;
```

By completing these procedures, the library function becomes available.

3.4 Use Developed Android Application on Android Device

In order to use the developed Android applications on the Android device, make the following settings on the Android device.

(NOTE) This procedure is based on the menu of Android 7.1. Menu contents may vary depending on the Android device to use.

- (1) Select [Settings], [Security], and turn on [Unknown sources]. (Figure 3-5)




Figure 3-5

- (2) Select [Settings], [Developer options], and turn on [USB debugging]. (Figure 3-6)




Figure 3-6

3.5 Precautions

- **About Scoped Storage**

"Scoped Storage" that is introduced in Android 10 distinguishes between app-specific storage and external storage.

When targeting Android 10 (API 29) or later, files that do not correspond to media files in the external storage cannot be handled directly. Files that do not correspond to media files can be handled by using the "Storage Access Framework".

See below for details of Scoped Storage.

- Data and file storage overview
<https://developer.android.com/training/data-storage>

Chapter 4

Functions of Library

This chapter describes the APIs of each class implemented in the library.

4.1 Standard Mode and Page Mode

4.1.1 Basic Operation


There are two printing modes "Standard mode" and "Page mode" in the library. The "Standard mode" and "Page mode" are described below.

(1) Standard mode

Standard mode is the mode to perform the printing in sequence.

Sample print command

- ① Send text data
- ② Print barcode
- ③ Send specified file (Specify an image file)



Standard mode suits the printing with an unfixed length such as a receipt.

(2) Page mode


Page mode is the mode to perform the printing on a per-page basis.

In page mode, the print area of page mode is allocated at first, and then print data is mapped on an arbitrary position of the print area.

The mapped print data is printed by the print method of page mode.

Sample print command

- ① Start page mode
- ② Specify print area of page mode
- ③ Send text data of page mode
- ④ Print barcode of page mode
- ⑤ Draw image file of page mode
- ⑥ Print page mode (print the data of ③④⑤ on the print area of ②)
- ⑦ End page mode



Page mode suits the printing for the followings.

- The printing with a fixed length.
- The printing with the coordinate determination of the character starting position or the ruled line printing position.

4.1.2 Text Data Printing in Standard Mode


The text data in standard mode is printed each one line.

The text data is stored in the printer when the text data less than one line is specified.


The stored text data is printed by either the following conditions.

- The text data filling for one line is specified.
- Line Feed code is specified.

- **The print process when the text data filling for one line is specified.**



- **The print process when Line Feed code is specified.**



4.1.3 Mapping Position of Print Data in Page Mode


In page mode, the mapping position of print data is determined by print area, print direction, and reference point.

This section describes the print area, print direction, and reference point.

(1) Print area of page mode

The print area of page mode is specified against the print area of the printer by the print area origin, and the width and the height of page mode. The view of the print area is shown in the following figures.

The print area of page mode can be specified more than one.




(2) Print direction

Specify the print direction at setting the print area of page mode.

The starting point is changed depending on specifying the print direction for each direction.


The relation between the print direction and the starting point is shown in the figure below.



- Starting point: Upper left (A on the figure), Print direction: Left to Right
- Starting point: Left below (B on the figure), Print direction: Below to Upper
- Starting point: Right below (C on the figure), Print direction: Right to Left
- Starting point: Upper right (D on the figure), Print direction: Upper to Below

(3) Reference point

The relation between the reference point for mapping data and each print element (text, image file, logo, and barcode, etc.) is shown in the figures below.





(NOTE) The reference point cannot be specified out of the print area of page mode.


4.1.4 Print Data Process at Out of Print Area of Page Mode

This section describes the process when mapped data is to be mapped on out of the print area of page mode.


Type of Print Data

Text	Barcode, 2-dimensional Barcode	Image File, Logo, Rectangle, Ruled Line
ABC		

- (1) The print data is mapped on the upper of the print area of page mode.



- (2) The print data is mapped on the right of print area of page mode.



(NOTE) Read error or incorrect reading may occur when the part of mapped barcode data is on out of the print area of page mode.

4.2 API Reference

The package of the library is **com.seikoinstruments.sdk.thermalprinter**.
com.seikoinstruments.sdk.thermalprinter includes the following classes.

Class Name	Description	Supported ^{*1}
PrinterManager	Provides the APIs used for communication with the printer and for printing. See " 4.2.1 PrinterManager Class " for more details.	✓
PrinterEvent	Provides the API that gets the end event when startDiscoveryPrinter is terminated. See " 4.2.2 PrinterEvent Class " for more details.	✓
PrinterListener	Interface for getting the end event when startDiscoveryPrinter is terminated. See " 4.2.3 PrinterListener Interface " for more details.	✓
PrinterInfo	Stores the printer information found by startDiscoveryPrinter . See " 4.2.4 PrinterInfo Class ".	✓
PrinterException	Exception class that is thrown at API call. See " 4.2.5 PrinterException Class " for more details.	✓
CallbackFunctionListener	Interface for getting the change event of printer status. See " 4.2.6 CallbackFunctionListener Interface " for more details.	✓
BarcodeScannerListener	Interface for getting barcode scanner connection or barcode scanner disconnection, or received barcode data. See " 4.2.7 BarcodeScannerListener Interface " for more details.	-

*1: ✓: Supported, -: Not supported

(NOTE) MP-B30/MP-B30L does not support the APIs of Display or the barcode scanner.

4.2.1 PrinterManager Class

(1) Method List

Methods provided by the **PrinterManager** class are shown in the following table.
"Standard mode" or "Page mode" can be selected in the **PrinterManager** class.

Method	Description
Common method to standard mode and page mode	The valid methods in standard mode and page mode. See "4.2.1(1)① Common method to standard mode and page mode" for the methods.
Dedicated method for standard mode	The valid methods in standard mode. See "4.2.1(1)② Dedicated method for standard mode" for the methods.
Dedicated method for page mode	The valid methods in page mode. See "4.2.1(1)③ Dedicated method for page mode" for the methods.

① Common method to standard mode and page mode

Methods provided by the common method to standard mode and page mode are shown in the following table. See "4.2.1(4)① Common method to standard mode and page mode" for details of the common methods.

Name	Description	Supported ^{*1}
PrinterManager	Constructor	✓
connect	Start communicating with printer (Bluetooth)	✓
connect	Start communicating with printer (USB)	✓
connect	Start communicating with printer (TCP/IP)	✓
disconnect	Stop communicating with printer	✓
setBarcodeScannerListener	Start/End callback of barcode scanner	-
openDrawer	Open cash drawer	-
buzzer	Sound buzzer	-
externalBuzzer	Sound external buzzer	-
getStatus	Get printer status	✓
setCallbackFunctionListener	Start/End callback of printer status change	✓
abort	Abort waiting state of printer	✓
registerLogo	Register logo	✓
unregisterLogo	Delete registered logo	✓
registerStyleSheet	Register style sheet	-
unregisterStyleSheet	Delete registered style sheet	-
resetPrinter	Reset printer	✓
getPrinterResponse	Get various responses from printer	✓
startDiscoveryPrinter	Start printer search (Bluetooth)	✓
startDiscoveryPrinter	Start printer search (USB)	✓

Name	Description	Supported ^{*1}
startDiscoveryPrinter	Start printer search (TCP/IP)	✓
cancelDiscoveryPrinter	Cancel printer search	✓
getFoundPrinter	Get found printer information	✓
getSendTimeout	Get send timeout period	✓
setSendTimeout	Set send timeout period	✓
getReceiveTimeout	Get receive timeout period	✓
setReceiveTimeout	Set receive timeout period	✓
getInternationalCharacter	Get international character set	✓
setInternationalCharacter	Set international character set	✓
getCodePage	Get codepage	✓
setCodePage	Set codepage	✓
getPrinterModel	Get printer model	✓
getPortType	Get connecting port type	✓
isConnect	Verify connection state with printer	✓
getSocketKeepingTime	Get socket keeping time	✓
setSocketKeepingTime	Set socket keeping time	✓
getVersion	Get SDK version	✓
controlTransaction	Start/End batch processing	✓

*1: ✓ : Supported, -: Not supported

② Dedicated method for standard mode

Methods provided by the dedicated method for standard mode are shown in the following table.
See "4.2.1(4)② Dedicated method for standard mode" for details of the dedicated methods.

Name	Description	Supported ^{*1}
sendText	Send text data	✓
sendTextEx	Send format specified text data	✓
printBarcode	Print barcode	✓
printPDF417	Print PDF417	✓
printQRcode	Print QR Code	✓
printDataMatrix	Print Data Matrix	✓
printMaxiCode	Print MaxiCode	✓
printGS1DataBarStacked	Print GS1 Databar Stacked	✓
printGS1DataBarStackedOmniDirectional	Print GS1 Databar Stacked Omni-directional	✓
printGS1DataBarExpandedStacked	Print GS1 Databar Expanded Stacked	✓
printAztecCode	Print Aztec Code	✓ ^{*2}
cutPaper	Cut paper ^{*3}	✓
feedPosition	Paper form feed	✓ ^{*2}
sendBinary	Send binary data	✓
sendDataFile	Send specified file	✓

Name	Description	Supported ^{*1}
printLogo	Print logo	✓

*1: ✓ : Supported, -: Not supported

*2: Supported only by MP-B30L.

*3: Only the paper feed operation to the paper cut position is performed.

③ Dedicated method for page mode

Methods provided by the dedicated method for page mode are shown in the following table.

See "4.2.1(4)③ Dedicated method for page mode" for details of the dedicated methods.

Name	Description	Supported ^{*1}
enterPageMode	Start page mode	✓
exitPageMode	End page mode	✓
setPageModeArea	Specify print area of page mode	✓
setPageModeDirection	Specify print direction of page mode	✓
setPageModeLineSpacing	Specify line spacing of page mode	✓
printPageMode	Print page mode	✓
printPageModeText	Send text data of page mode	✓
printPageModeTextEx	Send format specified text data of page mode	✓
printPageModeBarcode	Print barcode of page mode	✓
printPageModePDF417	Print PDF417 of page mode	✓
printPageModeQRcode	Print QR Code of page mode	✓
printPageModeDataMatrix	Print Data Matrix of page mode	✓
printPageModeMaxiCode	Print MaxiCode of page mode	✓
printPageModeGS1DataBarStacked	Print GS1 Databar Stacked of page mode	✓
printPageModeGS1DataBarStackedOmnidirectional	Print GS1 Databar Stacked Omni-directional of page mode	✓
printPageModeGS1DataBarExpandedStacked	Print GS1 Databar Expanded Stacked of page mode	✓
printPageModeAztecCode	Print Aztec Code of page mode	✓ ^{*2}
sendPageModeBinary	Send binary data of page mode	✓
printPageModeImageFile	Draw image file of page mode	✓
printPageModeRectangle	Draw rectangle image of page mode	✓
printPageModeLine	Print ruled line of page mode	✓
printPageModeLogo	Print logo of page mode	✓

*1: ✓ : Supported, -: Not supported

*2: Supported only by MP-B30L.

(2) Constant List

① Printer model

Constants used for starting communicating with a printer and getting the printer model are shown in the following table.

Constant Name	Description	Value
PRINTER_MODEL_MP_B30	MP-B30	302
PRINTER_MODEL_MP_B30L	MP-B30L	304
PRINTER_MODEL_DEFAULT	Default of printer model	284

② Response type

Constants used for getting various responses from a printer are shown in the following table.

Constant Name	Description	Value
PRINTER_RESPONSE_REQUEST	Request of execution response	0
PRINTER_RESPONSE_USER_AREA	Send remaining capacity of user area	1
PRINTER_RESPONSE_ARRANGE_USER_AREA	Send remaining capacity of user area after defragment	2
PRINTER_RESPONSE_NV_GRAPHICS	Send NV graphics memory capacity	3
PRINTER_RESPONSE_KEY_CODE	Send key code list of defined NV graphics	4
PRINTER_RESPONSE_BATTERY_STATUS	Battery remaining capacity level	5

③ Battery remaining capacity level

Constants of the battery remaining capacity level retrieved from a printer are shown in the following table.

Constant Name	Description	Value
BATTERY_STATUS_FULL	Battery remaining capacity: approx. 80%	0
BATTERY_STATUS_MIDDLE	Battery remaining capacity: approx. 40%	1
BATTERY_STATUS_LOW	Battery remaining capacity: approx. 10%	2
BATTERY_STATUS_EMPTY	No battery	3

④ International character set

Constants used for setting/getting international character set are shown in the following table.

Constant Name	Description	Value
COUNTRY_USA	USA	0
COUNTRY_FRANCE	France	1
COUNTRY_GERMANY	Germany	2
COUNTRY_ENGLAND	United Kingdom	3
COUNTRY_DENMARK_1	Denmark I	4
COUNTRY_SWEDEN	Sweden	5
COUNTRY_ITALY	Italy	6
COUNTRY_SPAIN	Spain I	7
COUNTRY_JAPAN	Japan	8
COUNTRY_NORWAY	Norway	9
COUNTRY_DENMARK_2	Denmark II	10
COUNTRY_SPAIN_2	Spain II	11
COUNTRY_LATIN_AMERICA	Latin America	12
COUNTRY_ARABIA	Arabia	17

⑤ Codepage

Constants used for setting/getting codepage are shown in the following table.

Constant Name	Description	Value
CODE_PAGE_437	USA, Standard Europe (Code Page 437)	0
CODE_PAGE_KATAKANA	Katakana	1
CODE_PAGE_850	Multilingual (Code Page 850)	2
CODE_PAGE_860	Portuguese (Code Page 860)	3
CODE_PAGE_863	Canadian-French (Code Page 863)	4
CODE_PAGE_865	Nordic (Code Page 865)	5
CODE_PAGE_857	Turkish (Code Page 857)	13
CODE_PAGE_737	Greek (Code Page 737)	14
CODE_PAGE_1252	Latin (Code Page 1252)	16
CODE_PAGE_866	Russian (Code Page 866)	17
CODE_PAGE_852	Eastern Europe (Code Page 852)	18
CODE_PAGE_858	Euro (Code Page 858)	19
CODE_PAGE_855	Cyrillic (Code Page 855)	34
CODE_PAGE_864 ^{*1*2}	Arabic (Code Page 864)	37
CODE_PAGE_1250	Central European (Code Page 1250)	45
CODE_PAGE_1251	Cyrillic (Code Page 1251)	46
CODE_PAGE_1253	Greek (Code Page 1253)	47
CODE_PAGE_1254	Turkish (Code Page 1254)	48

*1: 20ACh of the Unicode cannot be printed.

*2: Font B cannot be printed.

⑥ Port type

Constants used for starting communicating with a printer and getting the connecting port type are shown in the following table.

Constant Name	Description	Value
PRINTER_TYPE_BLUETOOTH	Bluetooth	0
PRINTER_TYPE_USB	USB	1
PRINTER_TYPE_TCP	TCP/IP	2

⑦ Barcode or PDF417

Constants used for printing barcode and printing PDF417 are shown in the following table.

Constant Name	Description	Value
BARCODE_HEIGHT_DEFAULT	Default of barcode height	162
PDF417_MODULE_HEIGHT_DEFAULT	Default of PDF417 height	10
PDF417_ROW_AUTO	Automatic selection of the number of rows	0
PDF417_COLUMN_AUTO	Automatic selection of the number of columns	0

(3) Enumerated Constant List

① Dithering (Dithering)

Constants of enumerated type used for dithering are shown in the following table.

Constant Name	Description
DITHERING_DISABLE	Dithering is disabled
DITHERING_ERRORDIFFUSION	Dithering is enabled

② Batch processing selection (TransactionFunction)

Constants of enumerated type used for batch processing selection are shown in the following table.

Constant Name	Description
TRANSACTION_CLEAR	Cancel batch processing
TRANSACTION_START	Start batch processing
TRANSACTION_PRINT	Finish batch printing and batch processing

③ Bold print (CharacterBold)

Constants of enumerated type used for bold print are shown in the following table.

Constant Name	Description
BOLD_CANCEL	Cancel bold print
BOLD	Specify bold print

④ Underline (CharacterUnderline)

Constants of enumerated type used for underlining are shown in the following table.

Constant Name	Description
UNDERLINE_CANCEL	Cancel underline print
UNDERLINE_1	Specify 1-dot width underline print
UNDERLINE_2	Specify 2-dot width underline print

⑤ Reverse print (CharacterReverse)

Constants of enumerated type used for reverse print are shown in the following table.

Constant Name	Description
REVERSE_CANCEL	Cancel reverse print
REVERSE	Specify reverse print

⑥ Inversion print (CharacterInversion)

Constants of enumerated type used for inversion print are shown in the following table.
Inversion print cannot be added to the text data before inserting a new line feed.

Constant Name	Description
INVERSION_CANCEL	Cancel inversion print
INVERSION	Specify inversion print

⑦ Character font (CharacterFont)

Constants of enumerated type used for character font are shown in the following table.

Constant Name	Description
FONT_A	Font A (24 × 12)
FONT_B	Font B (16 × 8)

⑧ Character scale (CharacterScale)

Constants of enumerated type used for character scale are shown in the following table.

Constant Name	Description
VERTICAL_1_HORIZONTAL_1	Height × 1 and width × 1
VERTICAL_1_HORIZONTAL_2	Height × 1 and width × 2
VERTICAL_1_HORIZONTAL_3	Height × 1 and width × 3
VERTICAL_1_HORIZONTAL_4	Height × 1 and width × 4
VERTICAL_2_HORIZONTAL_1	Height × 2 and width × 1
VERTICAL_2_HORIZONTAL_2	Height × 2 and width × 2
VERTICAL_2_HORIZONTAL_3	Height × 2 and width × 3
VERTICAL_2_HORIZONTAL_4	Height × 2 and width × 4
VERTICAL_2_HORIZONTAL_6	Height × 2 and width × 6
VERTICAL_3_HORIZONTAL_1	Height × 3 and width × 1
VERTICAL_3_HORIZONTAL_2	Height × 3 and width × 2
VERTICAL_3_HORIZONTAL_3	Height × 3 and width × 3
VERTICAL_3_HORIZONTAL_4	Height × 3 and width × 4
VERTICAL_4_HORIZONTAL_1	Height × 4 and width × 1
VERTICAL_4_HORIZONTAL_2	Height × 4 and width × 2
VERTICAL_4_HORIZONTAL_3	Height × 4 and width × 3
VERTICAL_4_HORIZONTAL_4	Height × 4 and width × 4
VERTICAL_4_HORIZONTAL_6	Height × 4 and width × 6
VERTICAL_4_HORIZONTAL_8	Height × 4 and width × 8
VERTICAL_6_HORIZONTAL_2	Height × 6 and width × 2
VERTICAL_6_HORIZONTAL_4	Height × 6 and width × 4
VERTICAL_6_HORIZONTAL_6	Height × 6 and width × 6
VERTICAL_6_HORIZONTAL_8	Height × 6 and width × 8
VERTICAL_8_HORIZONTAL_4	Height × 8 and width × 4
VERTICAL_8_HORIZONTAL_6	Height × 8 and width × 6
VERTICAL_8_HORIZONTAL_8	Height × 8 and width × 8

⑨ Alignment (PrintAlignment)

Constants of enumerated type used for alignment are shown in the following table.
Alignment cannot be added to the text data before inserting a new line feed.

Constant Name	Description
ALIGNMENT_LEFT	Aligned left
ALIGNMENT_CENTER	Centered
ALIGNMENT_RIGHT	Aligned right

⑩ Pending data output specifying (OutputPendingData)

Constants of enumerated type used for pending data output specifying are shown in the following table.

Constant Name	Description
PENDING_DATA_OUTPUT_FIRST	Output pending data at first and start the processing
PENDING_DATA_OUTPUT_TOGETHER	Output pending data at the same time as the processing

⑪ Barcode symbol (BarcodeSymbol)

Constants of enumerated type used for barcode symbol are shown in the following table.

Constant Name	Description	Syntax* ¹
BARCODE_SYMBOL_UPC_A	UPC-A	(a)
BARCODE_SYMBOL_UPC_E	UPC-E	(a)
BARCODE_SYMBOL_EAN13	EAN13	(a)
BARCODE_SYMBOL_JAN13	JAN13	(a)
BARCODE_SYMBOL_EAN8	EAN8	(a)
BARCODE_SYMBOL_JAN8	JAN8	(a)
BARCODE_SYMBOL_CODE39	CODE39	(a), (b)
BARCODE_SYMBOL_CODE93	CODE93	(c)
BARCODE_SYMBOL_CODE128	CODE128	(c)
BARCODE_SYMBOL_ITF	ITF	(a), (b)
BARCODE_SYMBOL_CODABAR	CODABAR	(a), (b)
BARCODE_SYMBOL_EAN13_ADDON	EAN13 add-on	(a)
BARCODE_SYMBOL_JAN13_ADDON	JAN13 add-on	(a)
BARCODE_SYMBOL_GS1_OMNI_DIRECTIONAL	GS1 Databar Omni-directional	(a)
BARCODE_SYMBOL_GS1_TRUNCATED	GS1 Databar Truncated	(a)
BARCODE_SYMBOL_GS1_LIMITED	GS1 Databar Limited	(a)
BARCODE_SYMBOL_GS1_EXPANDED	GS1 Databar Expanded	(a)

*1: See printBarcode or printPageModeBarcode for details of syntax.

⑫ Module size (ModuleSize)

Constants of enumerated type used for width, nominal fine element width, and module size of barcode are shown in the following table.

Constant Name	Description	Method to Use
BARCODE_MODULE_WIDTH_2	Fine element 2 dots Module width 0.250 mm	<ul style="list-style-type: none"> ● printBarcode ● printPageModeBarcode
BARCODE_MODULE_WIDTH_3	Fine element 3 dots Module width 0.375 mm	
BARCODE_MODULE_WIDTH_4	Fine element 4 dots Module width 0.500 mm	
BARCODE_MODULE_WIDTH_5	Fine element 5 dots Module width 0.625 mm	
BARCODE_MODULE_WIDTH_6	Fine element 6 dots Module width 0.750 mm	
PDF417_MODULE_WIDTH_2	Nominal fine element width 2 dots	<ul style="list-style-type: none"> ● printPDF417 ● printPageModePDF417
PDF417_MODULE_WIDTH_3	Nominal fine element width 3 dots	
PDF417_MODULE_WIDTH_4	Nominal fine element width 4 dots	
PDF417_MODULE_WIDTH_5	Nominal fine element width 5 dots	
PDF417_MODULE_WIDTH_6	Nominal fine element width 6 dots	
PDF417_MODULE_WIDTH_7	Nominal fine element width 7 dots	
PDF417_MODULE_WIDTH_8	Nominal fine element width 8 dots	
QR_MODULE_SIZE_2	2 dots	<ul style="list-style-type: none"> ● printQRcode ● printPageModeQRcode
QR_MODULE_SIZE_3	3 dots	
QR_MODULE_SIZE_4	4 dots	
QR_MODULE_SIZE_5	5 dots	
QR_MODULE_SIZE_6	6 dots	
QR_MODULE_SIZE_7	7 dots	
QR_MODULE_SIZE_8	8 dots	
QR_MODULE_SIZE_9	9 dots	
QR_MODULE_SIZE_10	10 dots	
QR_MODULE_SIZE_11	11 dots	
QR_MODULE_SIZE_12	12 dots	
QR_MODULE_SIZE_13	13 dots	
QR_MODULE_SIZE_14	14 dots	
QR_MODULE_SIZE_15	15 dots	
QR_MODULE_SIZE_16	16 dots	

Constant Name	Description	Method to Use
DATAMATRIX_MODULE_SIZE_2	2 dots	<ul style="list-style-type: none"> ● printDataMatrix ● printPageModeDataMatrix
DATAMATRIX_MODULE_SIZE_3	3 dots	
DATAMATRIX_MODULE_SIZE_4	4 dots	
DATAMATRIX_MODULE_SIZE_5	5 dots	
DATAMATRIX_MODULE_SIZE_6	6 dots	
DATAMATRIX_MODULE_SIZE_7	7 dots	
DATAMATRIX_MODULE_SIZE_8	8 dots	
DATAMATRIX_MODULE_SIZE_9	9 dots	
DATAMATRIX_MODULE_SIZE_10	10 dots	
DATAMATRIX_MODULE_SIZE_11	11 dots	
DATAMATRIX_MODULE_SIZE_12	12 dots	
DATAMATRIX_MODULE_SIZE_13	13 dots	
DATAMATRIX_MODULE_SIZE_14	14 dots	
DATAMATRIX_MODULE_SIZE_15	15 dots	
DATAMATRIX_MODULE_SIZE_16	16 dots	
GS1DATABAR_MODULE_SIZE_2	2 dots	<ul style="list-style-type: none"> ● printGS1DataBarStacked ● printGS1DataBarStackedOmnidirectional ● printGS1DataBarExpandedStacked ● printPageModeGS1DataBarStacked ● printPageModeGS1DataBarStackedOmnidirectional ● printPageModeGS1DataBarExpandedStacked
GS1DATABAR_MODULE_SIZE_3	3 dots	
GS1DATABAR_MODULE_SIZE_4	4 dots	
GS1DATABAR_MODULE_SIZE_5	5 dots	
GS1DATABAR_MODULE_SIZE_6	6 dots	
GS1DATABAR_MODULE_SIZE_7	7 dots	
GS1DATABAR_MODULE_SIZE_8	8 dots	
GS1DATABAR_MODULE_SIZE_9	9 dots	
GS1DATABAR_MODULE_SIZE_10	10 dots	
GS1DATABAR_MODULE_SIZE_11	11 dots	
GS1DATABAR_MODULE_SIZE_12	12 dots	
GS1DATABAR_MODULE_SIZE_13	13 dots	
GS1DATABAR_MODULE_SIZE_14	14 dots	
GS1DATABAR_MODULE_SIZE_15	15 dots	
GS1DATABAR_MODULE_SIZE_16	16 dots	
AZTECCODE_MODULE_SIZE_2	2 dots	<ul style="list-style-type: none"> ● printAztecCode ● printPageModeAztecCode
AZTECCODE_MODULE_SIZE_3	3 dots	
AZTECCODE_MODULE_SIZE_4	4 dots	
AZTECCODE_MODULE_SIZE_5	5 dots	
AZTECCODE_MODULE_SIZE_6	6 dots	
AZTECCODE_MODULE_SIZE_7	7 dots	
AZTECCODE_MODULE_SIZE_8	8 dots	
AZTECCODE_MODULE_SIZE_9	9 dots	
AZTECCODE_MODULE_SIZE_10	10 dots	
AZTECCODE_MODULE_SIZE_11	11 dots	

Constant Name	Description	Method to Use
AZTECCODE_MODULE_SIZE_12	12 dots	<ul style="list-style-type: none"> ● printAztecCode ● printPageModeAztecCode
AZTECCODE_MODULE_SIZE_13	13 dots	
AZTECCODE_MODULE_SIZE_14	14 dots	
AZTECCODE_MODULE_SIZE_15	15 dots	
AZTECCODE_MODULE_SIZE_16	16 dots	

⑬ HRI character print position (HriPosition)

Constants of enumerated type used for HRI character print position are shown in the following table.

Constant Name	Description
HRI_NONE	Not printed
HRI_POSITION_ABOVE	Above barcode
HRI_POSITION_BELOW	Below barcode
HRI_POSITION_ABOVE_BELOW	Above and below barcode (both)

⑭ N:W ratio (NwRatio)

Constants of enumerated type used for N:W ratio are shown in the following table.

Constant Name	Description
NWRATIO_1TO2	1:2
NWRATIO_1TO2_5	1:2.5
NWRATIO_1TO3	1:3

⑮ Error correction level (ErrorCorrection)

Constants of enumerated type used for error correction level are shown in the following table.

Constant Name	Description	Method to Use
PDF417_ERROR_CORRECTION_0	Error correction level 0	<ul style="list-style-type: none"> ● printPDF417 ● printPageModePDF417
PDF417_ERROR_CORRECTION_1	Error correction level 1	
PDF417_ERROR_CORRECTION_2	Error correction level 2	
PDF417_ERROR_CORRECTION_3	Error correction level 3	
PDF417_ERROR_CORRECTION_4	Error correction level 4	
PDF417_ERROR_CORRECTION_5	Error correction level 5	
PDF417_ERROR_CORRECTION_6	Error correction level 6	
PDF417_ERROR_CORRECTION_7	Error correction level 7	
PDF417_ERROR_CORRECTION_8	Error correction level 8	

Constant Name	Description	Method to Use
QR_ERROR_CORRECTION_L	Error correction level L	<ul style="list-style-type: none"> ● printQRcode ● printPageModeQRcode
QR_ERROR_CORRECTION_M	Error correction level M	
QR_ERROR_CORRECTION_H	Error correction level H	
QR_ERROR_CORRECTION_Q	Error correction level Q	

⑩ PDF417 symbol (Pdf417Symbol)

Constants of enumerated type used for PDF417 symbol are shown in the following table.

Constant Name	Description
PDF417_STANDARD	PDF417
PDF417_COMPACT	Compact PDF417

⑪ QR Code Model (QrModel)

Constants of enumerated type used for QR Code Model are shown in the following table.

Constant Name	Description
QR_MODEL_1	QR Code Model 1
QR_MODEL_2	QR Code Model 2

⑫ Data Matrix module (DataMatrixModule)

Constants of enumerated type used for Data Matrix module are shown in the following table.

Constant Name	Description
DATA_MATRIX_AUTO	Number of modules: Automatic
DATA_MATRIX_10_10	Number of modules: 10 × 10
DATA_MATRIX_12_12	Number of modules: 12 × 12
DATA_MATRIX_14_14	Number of modules: 14 × 14
DATA_MATRIX_16_16	Number of modules: 16 × 16
DATA_MATRIX_18_18	Number of modules: 18 × 18
DATA_MATRIX_20_20	Number of modules: 20 × 20
DATA_MATRIX_22_22	Number of modules: 22 × 22
DATA_MATRIX_24_24	Number of modules: 24 × 24
DATA_MATRIX_26_26	Number of modules: 26 × 26
DATA_MATRIX_32_32	Number of modules: 32 × 32
DATA_MATRIX_36_36	Number of modules: 36 × 36
DATA_MATRIX_40_40	Number of modules: 40 × 40
DATA_MATRIX_44_44	Number of modules: 44 × 44

Constant Name	Description
DATA_MATRIX_48_48	Number of modules: 48 × 48
DATA_MATRIX_52_52	Number of modules: 52 × 52
DATA_MATRIX_64_64	Number of modules: 64 × 64
DATA_MATRIX_72_72	Number of modules: 72 × 72
DATA_MATRIX_80_80	Number of modules: 80 × 80
DATA_MATRIX_88_88	Number of modules: 88 × 88
DATA_MATRIX_96_96	Number of modules: 96 × 96
DATA_MATRIX_104_104	Number of modules: 104 × 104
DATA_MATRIX_120_120	Number of modules: 120 × 120
DATA_MATRIX_132_132	Number of modules: 132 × 132
DATA_MATRIX_144_144	Number of modules: 144 × 144
DATA_MATRIX_8_18	Number of modules: 8 × 18
DATA_MATRIX_8_32	Number of modules: 8 × 32
DATA_MATRIX_12_26	Number of modules: 12 × 26
DATA_MATRIX_12_36	Number of modules: 12 × 36
DATA_MATRIX_16_36	Number of modules: 16 × 36
DATA_MATRIX_16_48	Number of modules: 16 × 48

①9 MaxiCode Mode (MaxiCodeMode)

Constants of enumerated type used for MaxiCode Mode are shown in the following table.

Constant Name	Description
MAXI_CODE_2	Mode2
MAXI_CODE_3	Mode3
MAXI_CODE_4	Mode4
MAXI_CODE_5	Mode5

②0 Aztec Symbol (AztecSymbol)

Constants of enumerated type used for Aztec Symbol are shown in the following table.

Constant Name	Description
AZTECCODE_FULLRANGE	Full-range
AZTECCODE_COMPACT	Compact

㉑ Cutting method (CuttingMethod)

Constants of enumerated type used for cutting method are shown in the following table.

Constant Name	Description
CUT_FULL	No cut Paper feed operation to the paper cut position
CUT_PARTIAL	
CUT_NONE ^{*1}	No cut

*1: Supported only by **printPageMode**.

㉒ Form feed position (FeedPosition)


Constants of enumerated type used for form feed position of marked paper or label are shown in the following table.

Constant Name	Description
FEED_CUTTER	After detecting the mark or the gap, feeds the paper to the cutting position. The paper feed length is the length of the memory switches MS 21 to 22 (Mark Detection Cut Position Correction) of the printer. The default of the paper feed is 125 dots (15.6 mm).
FEED_NEXT_TOF	After detecting the next mark or the gap, feeds the paper to the printing position. The paper feed length is the length of the memory switches MS 26 to 27 (Mark Detection Print Position Correction) of the printer. The default of the paper feed is 125 dots (15.6 mm).

Reference See "User's Guide" for details of the memory switch of the printer.
The memory switch of the printer can be changed in the Android app "SII Printer Utility" on the Google Play.

The relation between the sensor position and the defaults of the memory switches MS 21 to 22 (Mark Detection Cut Position Correction) of the printer and the memory switches MS 26 to 27 (Mark Detection Print Position Correction) of the printer are shown in the following figure.


When the memory switch of the printer is set to the default, the cutting position of **FEED_CUTTER** and the next printing position of **FEED_NEXT_TOF** is the same paper feed length.



Unit : mm

To set to shorter the next print position for the mark to save paper, set the values of the memory switches MS 26 to 27 (Mark Detection Print Position Correction) of the printer shorter.

As an example, the relation of the sensor position when the values of the memory switches MS 26 to 27 of the printer are set to 103 dots (12.8 mm) and paper form feed is performed with specifying **FEED_NEXT_TOF** is shown in the following figure.




Unit : mm

Note When using label, set the values of the memory switches MS 26 to 27 (Mark Detection Print Position Correction) of the printer so that the print position can be inside the label.

②③ Print direction (Direction)

Constants of enumerated type used for print direction in page mode are shown in the following table.

Constant Name	Description
DIRECTION_LEFT_TO_RIGHT	Starting point: Upper left (A on the figure), Print direction: Left to Right
DIRECTION_BOTTOM_TO_TOP	Starting point: Left below (B on the figure), Print direction: Below to Upper
DIRECTION_RIGHT_TO_LEFT	Starting point: Right below (C on the figure), Print direction: Right to Left
DIRECTION_TOP_TO_BOTTOM	Starting point: Upper right (D on the figure), Print direction: Upper to Below



②④ Line style (LineStyle)

Constants of enumerated type used for line style in page mode are shown in the following table.

Constant Name	Description
LINESTYLE_THIN	Thin solid line (2 dots)
LINESTYLE_MEDIUM	Medium solid line (4 dots)
LINESTYLE_THICK	Thick solid line (8 dots)

(4) Method Details

① Common method to standard mode and page mode

The following methods are valid in standard mode and page mode. Standard mode is set immediately after **connect** is executed.

PrinterManager	Constructor
----------------	-------------

Constructor for **com.seikoinstruments.sdk.thermalprinter.PrinterManager** class.

Syntax `public PrinterManager(Context context)`

Parameter *context* Specify application context to call this method.
Example: **MainActivity.this**

connect	Start communicating with printer (Bluetooth)
---------	--

Starts communication with a printer by Bluetooth connection.

The method of syntax (a) always communicates with a printer in secure mode.

The method of syntax (b) communicates with a printer by specifying secure mode or insecure mode.

Syntax (a) `public void connect(int printerModel, String address)` throws **PrinterException**

(b) `public void connect(int printerModel, String address, boolean secure)` throws **PrinterException**

Parameter *printerModel* Printer model constant for Bluetooth connection
See "4.2.1(2)① Printer model" for available constants.

address Bluetooth address
Example: "00:11:22:AA:BB:CC"

secure true Communicates with a printer in secure mode
false Communicates with a printer in insecure mode
Normally, communication in secure mode is recommended.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Call this method before using other **Printer Manager** class methods.

The printer specified by *printerModel* is connected to the Bluetooth address specified by *address*.

Also, printer initial setting is performed at the connection based on *printerModel* specified.

Monitoring of the printer status is started with this method. The latest printer status can be retrieved from **getStatus**.

Changes of the printer status can be notified as events by **onStatusChanged** and **setCallbackFunctionListener**.

Starts communication with a printer by USB connection.

Syntax `public void connect(int printerModel)` throws **PrinterException**

Parameter *printerModel* Printer model constant for USB connection
See "4.2.1(2)① Printer model" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Call this method before using other **Printer Manager** class methods.

The printer specified by *printerModel* is connected.
Also, printer initial setting is performed at the connection based on *printerModel* specified.

Monitoring of the printer status is started with this method. The latest printer status can be retrieved from `getStatus`.
Changes of the printer status can be notified as events by `onStatusChanged` and `setCallbackFunctionListener`.

Starts communication with a printer by TCP/IP connection.

Syntax `public void connect(int printerModel, String address)` throws **PrinterException**

Parameter *printerModel* Printer model constant for Ethernet connection
See "4.2.1(2)① Printer model" for available constants.

address IP address
Example: "192.168.0.190"

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Call this method before using other **PrinterManager** class methods.

Starts communication with a printer connected to the same network as the Android device by TCP/IP connection.

Connects to the IP address specified by *address*. TCP ports 9100 and 26100 are used for communication. Also, printer initial setting is performed at the connection based on *printerModel* specified.

•Creating/discarding of socket in TCP/IP connection of the library

After **connect**, the library retains the created socket until **disconnect**.
And connecting to the same printer from other applications is not possible until **disconnect**.

Based on the completion of data transmission to the printer, the socket is once discarded after elapsing socket keeping time set by `setSocketKeepingTime`. Then the new socket is created immediately and used for the next connection.

Changes of the printer status can be notified as events by `onStatusChanged` and `setCallbackFunctionListener`.

Stop communicating with printer

Syntax public void **disconnect()** throws **PrinterException**

Description	This method discards the print data kept by controlTransaction . The instance of CallbackFunctionListener interface kept by setCallbackFunctionListener is discarded and the callback is stopped.
-------------	---

Note It is recommended to get the execution response by **PRINTER_RESPONSE_REQUEST** of **getPrinterResponse** before executing this method. If not, the communication is disconnected by this method before the print data sending from Android device to the printer is completed, and a part of the data may be lost.

If you do not execute **getPrinterResponse** in your program, evaluate your program to confirm no problems arise.

Start/End callback of barcode scanner

Syntax

```
public void setBarcodeScannerListener(BarcodeScannerListener listener)
```

throws PrinterException

Open cash drawer

Syntax `public void openDrawer(DrawerNum drawerNum, PulseWidth onOffTime)` throws **PrinterException**

Sound buzzer

Syntax `public void buzzer(int onTime, int offTime) throws PrinterException`

Sound external buzzer

Syntax

```
public void externalBuzzer(BuzzPattern buzzer pattern, int buzzerCount)  
    throws PrinterException
```

Gets the latest printer status.

The method of syntax (a) returns the printer status with return value.

The method of syntax (b) stores the printer status in an array of int type.

Syntax (a) public int **getStatus()** throws **PrinterException**

(b) public void **getStatus**(int [] *buf*) throws **PrinterException**

Return value Status retrieved from the printer

Parameter *buf* Status retrieved from the printer

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called.

See "**4.2.5 PrinterException Class**" for details of the error.

When the data transmission is failed, the communication with the printer is ended, and

PrinterException may be thrown. See **isConnect** for verifying the connection state with the printer.

Description The printer status is shown below.

When the connection failed, the printer status is shown in 0x80000000.

Bit	Function	Value	
		0	1
0	Voltage error	No error	Error
1	Hardware error	No error	Error
2	Head temperature error	No error	Error
3	Reserved	Fixed	-
4	Out-of-paper error	No error	Error
5	Reserved	Fixed	-
6	MP-B30: Paper jam error while detecting mark MP-B30L: Paper jam error while detecting mark or gap	No error	Error
7	Cover open error	No error	Error
8	FEED Switch status	OFF	ON
9	Reserved	Fixed	-
10	Paper feed status	Stop	Operating
11	Return-waiting status	Not waiting	Waiting
12	Reserved	Fixed	-
13	Reserved	-	Fixed
14	Reserved	-	Fixed
15	Reserved	-	Fixed
16	FLASH memory rewriting	Not rewriting	Rewriting
17	Reserved	-	Fixed
18	Reserved	-	Fixed
19	Reserved	-	Fixed

Registers image file to NV graphics memory in the printer as a logo.

The method of syntax (a), dithering is fixed to be disabled.

The method of syntax (b), dithering can be specified.

Syntax	(b) public void registerLogo (String <i>fileName</i> , String <i>id</i>) throws PrinterException
	(a) public void registerLogo (String <i>fileName</i> , String <i>id</i> , Dithering <i>dithering</i>) throws PrinterException
Parameter	<p><i>fileName</i> File name of image file to register as a logo The formats that can be entered are described below.</p> <ul style="list-style-type: none"> • Absolute path string handled by Java standard class "java.io.File" When targeting Android 10 (API 29) or later, please note that some files cannot be handled directly. See "3.5 Precautions - About Scoped Storage" for details. • URI string of the following scheme name handled by the class "android.net.Uri" prepared for Android <ul style="list-style-type: none"> • file:// • content:// It is necessary to specify the URI string obtained from "Storage Access Framework" for this parameter. Please note that URI created without being obtained from "Storage Access Framework" may not be able to open the file. <p>The file extensions supporting image file are .bmp, .jpg, .jpeg, and .png. When the image file is colored, it is converted to monochrome image by binarization and registered.</p> <p><i>id</i> Logo ID to register (key code) Specify the logo ID to register by character string of 2 characters. The valid characters are ASCII character code from 20h (space) to 7Eh (tilde) such as alphanumeric ('0' to '9', 'A' to 'Z', 'a' to 'z').</p> <p><i>dithering</i> Dithering See "4.2.1(3)① Dithering (Dithering)" for available constants.</p>
Exception	<p>PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.</p>

Deletes the registered logo.

Syntax	public void unregisterLogo (String <i>id</i>) throws PrinterException
Parameter	<p><i>id</i> Logo ID to delete (key code) Specify the ID of the registered logo as a character string.</p>

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
 See "**4.2.5 PrinterException Class**" for details of the error.
 When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

registerStyleSheet	Register style sheet
---------------------------	-----------------------------

This method is not supported. When this method is executed, **PrinterException** is thrown.

Syntax public void **registerStyleSheet**(String *fileName*, int *num*) throws **PrinterException**

unregisterStyleSheet	Delete registered style sheet
-----------------------------	--------------------------------------

This method is not supported. When this method is executed, **PrinterException** is thrown.

Syntax public void **unregisterStyleSheet**(int *num*) throws **PrinterException**

resetPrinter	Reset printer
---------------------	----------------------

Resets the printer hardware.

Syntax public void **resetPrinter**() throws **PrinterException**

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
 See "**4.2.5 PrinterException Class**" for details of the error.
 When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

Description For Bluetooth connection:
 The printer hardware reset is performed by the printer command "Printer Reset".

 For USB connection:
 The printer reset is performed by using the SOFT_RESET function in USB printer class.

 For TCP/IP connection:
 The reset is performed to the connected printer by our proprietary command (reset request) to TCP port 26100.

 The connection with the printer is retained even after this method is executed.

getPrinterResponse	Get various responses from printer
---------------------------	---

Gets response data from the printer.

Syntax public void **getPrinterResponse**(int *id*, Object *buf*) throws **PrinterException**

Parameter *id* Response type constant
 See "4.2.1(2)② Response type" for available constants.

buf

Buffer that stores the retrieved response data
This method stores the response data specified by *id* to the object specified by *buf*.
The buffer type varies depending on the response type constant.
See the following table for buffer types.

Response Type Constant		
Parameter	Description	
PRINTER_RESPONSE_REQUEST (Execution response request)		
buf	Specify an int type array of length 1. Specify 0 to 15 (00h to 0Fh) for buf[0]. When the response is retrieved successfully, the response code of the execution response request is stored to buf[0] with 128 to 143 (80h to 8Fh).	
PRINTER_RESPONSE_USER_AREA (Send remaining capacity of user area)		
buf	Specify an int type array of length 1. When the response is retrieved successfully, the remaining capacity of the user area is stored as a numerical value in bytes.	
PRINTER_RESPONSE_ARRANGE_USER_AREA (Send remaining capacity of user area after defragment)		
buf	Specify an int type array of length 1. When the response is retrieved successfully, the remaining capacity of the user area after defragment is stored as a numerical value in bytes.	
PRINTER_RESPONSE_NV_GRAPHICS (Send NV graphics memory capacity)		
buf	Specify an int type array of length 1. When the response is retrieved successfully, the NV graphics memory capacity is stored as a numerical value in bytes.	
PRINTER_RESPONSE_KEY_CODE (Send key code list of defined NV graphics)		
buf	Specify an ArrayList<String> array. When the response is retrieved successfully, the key code of NV graphics is stored as a string array. Example: buf.size() = 3, buf[0] = "22", buf[1] = "23", buf[2] = "24", etc.	
PRINTER_RESPONSE_BATTERY_STATUS (Battery remaining capacity level)		
buf	Specify an int type array of length 1. When the response is retrieved successfully, the battery remaining capacity level is stored as a value. See "4.2.1(2)③ Battery remaining capacity level" for details of the value. Battery remaining capacity level BATTERY_STATUS_FULL : Full (Battery remaining capacity: approx. 80%) BATTERY_STATUS_MIDDLE : Middle (Battery remaining capacity: approx. 40%) BATTERY_STATUS_LOW : Low (Battery remaining capacity: approx. 10%) BATTERY_STATUS_EMPTY : No battery	

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

Start printer search (Bluetooth)

Searches for the printer using the Bluetooth connection. The found printer information is stored in **PrinterInfo** class.

Syntax `public void startDiscoveryPrinter(PrinterListener listener) throws PrinterException`

Parameter	<i>listener</i>	Instance of PrinterListener Completion of this method or cancellation by cancelDiscoveryPrinter is notified to the user application as an end event by finishEvent through the instance set in <i>listener</i> .
-----------	-----------------	--

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
 See "**4.2.5 PrinterException Class**" for details of the error.

Description	This method may discover other printers besides SII printer. In addition, the printers in which the Bluetooth connection is already established by the library or other applications are not found.
-------------	--

Do not call this method from the main thread of the application.

Start printer search (USB)

Searches for the printer using the USB connection. The found printer information is stored in **PrinterInfo** class.

Syntax

```
public void startDiscoveryPrinter(PrinterListener listener, int deviceType) throws PrinterException
```

Parameter	<i>listener</i>	Instance of PrinterListener Completion of this method or cancellation by cancelDiscoveryDevice is notified to the user application as an end event by finishEvent through the instance set in <i>listener</i> .
-----------	-----------------	---

deviceType Port type
Specify **PRINTER TYPE USB**.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
 See **"4.2.5 PrinterException Class"** for details of the error.

Description	This method searches for SII printer. The printer information of the found printer is stored to PrinterInfo class described later.
-------------	---

Start printer search (TCP/IP)

Searches for SII printer connecting to the same network.

Syntax public void **startDiscoveryPrinter**(*PrinterListener listener*, int *retry*, int *timeout*) throws **PrinterException**

Parameter	<i>listener</i>	Instance of PrinterListener Completion of this method or cancellation by cancelDiscoveryPrinter is notified to the user application as an end event by finishEvent through the instance set in <i>listener</i> .
-----------	-----------------	--

<i>retry</i>	<p>Retry count (times)</p> <p>Sends the local broadcast packet the number of times set by <i>retry</i>.</p> <p>The valid range is 1 to 5.</p> <p>When the value is specified less than 1, the number is set to 1.</p> <p>When the value is specified more than 5, the number is set to 5.</p>
<i>timeout</i>	<p>Search timeout period (millisecond: ms)</p> <p>Sets the timeout period per search. Each time the local broadcast packet is sent, this method waits for a response from the printer until the period specified by <i>timeout</i> elapses.</p> <p>The valid range is 3000 to 60000.</p> <p>When the value is specified less than 3000, the period is set to 3000 ms.</p> <p>When the value is specified more than 60000, the period is set to 60000 ms.</p>
Error	PrinterException is thrown when an error occurs while this method is being called.
Description	<p>This method searches for SII printer. The printer information of the found printer is stored to PrinterInfo class described later.</p> <p>The completion or cancellation of the search is notified as an event to the user application by finishEvent through the instance set in <i>listener</i>.</p>

cancelDiscoveryPrinter

Cancel printer search

Cancels **startDiscoveryPrinter** under execution.

Syntax `public void cancelDiscoveryPrinter()`

Description Cancellation by this method is notified as an end event to the user application by **finishEvent** through the instance set in *listener* of **startDiscoveryPrinter**.

getFoundPrinter

Get found printer information

Gets the information of the printer found by **startDiscoveryPrinter** in ArrayList from the **PrinterInfo** class, which is the storage destination.

Syntax `public ArrayList<PrinterInfo> getFoundPrinter()`

Return value ArrayList of **PrinterInfo** class

getSendTimeout

Get send timeout period

Gets the send timeout period.

Syntax `public int getSendTimeout()`

Return value Send timeout period (millisecond: ms)

Description This method can get the send timeout period regardless of whether **isConnect** is true or false.

setSendTimeout**Set send timeout period**

Sets the send timeout period.

Syntax `public void setSendTimeout(int sendTimeout)`

Parameter *sendTimeout* Send timeout period (millisecond: ms)
The valid range is 100 to 90000.
When the value out of the valid range is specified, the value is set to 10000 ms.

Description When the send timeout period is not set by this method, the value is set to 10000.

This method can set the send timeout period regardless of whether **isConnect** is true or false.

The set timeout period becomes effective at the next data sending.

getReceiveTimeout**Get receive timeout period**

Gets the receive timeout period.

Syntax `public int getReceiveTimeout()`

Return value Receive timeout period (millisecond: ms)

Description This method can get the receive timeout period regardless of whether **isConnect** is true or false.

setReceiveTimeout**Set receive timeout period**

Sets the receive timeout period.

Syntax `public void setReceiveTimeout(int receiveTimeout)`

Parameter *receiveTimeout* Receive timeout period (millisecond: ms)
The valid range is 100 to 90000.
When the value out of the valid range is specified, the value is set to 10000 ms.

Description When the receive timeout period is not set by this method, the value is set to 10000.

This method can set the receive timeout period regardless of whether **isConnect** is true or false.

The set timeout period becomes effective at the next data receiving.

getInternationalCharacter**Get international character set**

Gets the value of international character set.

Syntax `public int getInternationalCharacter()`

Return value See "4.2.1(2)④ International character set" for details of the value.

Description When the text data is sent by **sendText**, **sendTextEx**, **sendDataFile**, **printPageModeText** or **printPageModeTextEx**, the print result of the following character codes varies. See "Appendix A Character Set" for details about characters to be printed.

Character codes with the varying print result depending on the configuration of the international character:
0x23, 0x24, 0x40, 0x5B, 0x5C, 0x5D, 0x5E, 0x60, 0x7B, 0x7C, 0x7D, 0x7E

setInternationalCharacter

Set international character set

Sets the value of international character set.

Syntax `public void setInternationalCharacter(int internationalCharacter)`

Parameter *internationalCharacter* International character set constant
See "4.2.1(2)④ International character set" for the configurable values.
When an invalid value is specified, it is ignored.

Description When the international character set is not set by this method, it is as follows depending on the language setting of an Android device.
When the language setting of the Android device is Japanese:
COUNTRY_JAPAN
When the language setting of the Android device is other than Japanese:
COUNTRY_USA

getCodePage

Get codepage

Gets the value of codepage.

Syntax `public int getCodePage()`

Return value See "4.2.1(2)⑤ Codepage" for details of the value.

Description The encoder used for sending the text data by **sendText**, **sendTextEx**, **sendDataFile**, **printPageModeText**, or **printPageModeTextEx** is changed. See "Appendix A Character Set" for details about characters to be printed.

setCodePage

Set codepage

Sets the value of codepage.

Syntax `public void setCodePage(int codePage)`

Parameter *codePage* Codepage constant
See "4.2.1(2)⑤ Codepage" for the configurable values.
When an invalid value is specified, it is ignored.

Description When the codepage is not set by this method, it is as follows depending on the language setting of an Android device.
When the language setting of the Android device is Japanese:
CODE_PAGE_KATAKANA
When the language setting of the Android device is other than Japanese:
CODE_PAGE_1252

getPrinterModel

Get printer model

Gets the value of the connecting printer model.

Syntax public int **getPrinterModel()**

Return value See "4.2.1(2)① Printer model" for details of the value.
PRINTER_MODEL_DEFAULT is returned when **isConnect** is false.

Description Even when the printer is not connected, when **connect** has succeeded once, the printer model value successfully connected last time is returned.

getPortType

Get connecting port type

Gets the port type used for connecting with the printer.

Syntax public int **getPortType()**

Return value See "4.2.1(2)⑥ Port type" for details of the value.
PRINTER_TYPE_BLUETOOTH is returned when **isConnect** is false.

Description Even when the printer is not connected, when **connect** has been succeeded once, the port type value successfully connected last time is returned.

isConnect

Verify connection state with printer

Verifies connection state with the printer.

Syntax public boolean **isConnect()**

Return value true Connected to a printer
false Not connected to a printer

Description When the data transmission is failed, the communication with the printer is ended, and this method returns false. When false is returned, reconnect with the printer by **connect**.

getSocketKeepingTime

Get socket keeping time

Gets the socket keeping time.

Syntax public int **getSocketKeepingTime()**

Return value Socket keeping time (millisecond: ms)

Description This method can get the socket keeping time regardless of whether **isConnect** is true or false.

setSocketKeepingTime

Set socket keeping time

Sets the socket keeping time.

Syntax public void **setSocketKeepingTime**(int *socketKeepingTime*)

Valid range 60000 to 300000 (millisecond: ms)
When the value is specified less than 60000, the time is set to 60000 ms.
When the value is specified more than 300000, the time is set to 300000 ms.

Default	300000
Description	<p>This method can set the socket keeping time regardless of whether isConnect is true or false.</p> <p>For the socket keeping time, specify a time equal to Receive Timeout of the printer to be connected. The setting of Receive Timeout can be changed in the Android app "SII Printer Utility" on the Google Play.</p> <p>The set socket keeping time becomes effective at the next connect execution.</p>

getVersion	Get SDK version
-------------------	-----------------

Gets the SDK version as a character string.

Syntax	<code>public String getVersion()</code>
Return value	SDK version character string (Example: When the SDK version is Ver.1.0.0, the return value is "1.0.0")
Description	This method can get the SDK version regardless of whether isConnect is true or false.

controlTransaction	Start/End batch processing
---------------------------	----------------------------

Starts or ends batch processing.

Syntax	<code>public void controlTransaction(TransactionFunction <i>transactionFunction</i>)</code> throws PrinterException
Parameter	<i>transactionFunction</i> Batch processing selection See "4.2.1(3)② Batch processing selection (TransactionFunction)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error. When data transmission fails, communication with the printer may be terminated and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.
Description	<p>The procedure of batch processing is as follows:</p> <ol style="list-style-type: none"> (1) Start batch processing. Specify TRANSACTION_START. (2) Execute the method. In the case of the batch processing target method, buffering of transmission data is started. The transmission data of the batch processing target method executed during buffering is buffered in the transmission buffer without being sent to the printer. The maximum size of transmission data to be buffered is system dependent. If the buffered transmission data exceeds the maximum size, the batch processing target method at the time of exceeding becomes an error. If an error occurs, the transmission data up to the error is retained. As for the retained transmission data, finish the batch processing in step (3). In the case of a method other than the batch processing target method, transmission data is immediately executed without being buffered.

(3) Finish batch processing.

When **TRANSACTION_PRINT** is specified, the buffered transmission data is sent to the printer. The buffered transmission data is retained even after sent to the printer.

The retained transmission data is discarded by any of the following:

- Specify **TRANSACTION_CLEAR**
- Specify **TRANSACTION_START**
- Execute **disconnect**

The batch processing target methods are as follows:

- **sendText**
- **sendTextEx**
- **printBarcode**
- **printPDF417**
- **printQRcode**
- **printDataMatrix**
- **printMaxiCode**
- **printGS1DataBarStacked**
- **printGS1DataBarStackedOmnidirectional**
- **printGS1DataBarExpandedStacked**
- **printAztecCode**^{*1}
- **cutPaper**
- **feedPosition**^{*1}
- **sendBinary**
- **sendDataFile**
- **printLogo**^{*2}
- **enterPageMode**
- **exitPageMode**
- **setPageModeArea**
- **setPageModeDirection**
- **setPageModeLineSpacing**
- **printPageMode**
- **printPageModeText**
- **printPageModeTextEx**
- **printPageModeBarcode**
- **printPageModePDF417**
- **printPageModeQRcode**
- **printPageModeDataMatrix**
- **printPageModeMaxiCode**
- **printPageModeGS1DataBarStacked**
- **printPageModeGS1DataBarStackedOmnidirectional**
- **printPageModeGS1DataBarExpandedStacked**
- **printPageModeAztecCode**^{*1}
- **sendPageModeBinary**
- **printPageModeImageFile**
- **printPageModeRectangle**
- **printPageModeLine**
- **printPageModeLogo**^{*2}

*1: Supported only by MP-B30L.

*2: The method under batch processing does not notify the error even when the registered logo does not exist.

② Dedicated method for standard mode

The following methods are valid in standard mode. **PrinterException** is thrown when the dedicated method for standard mode are executed in page mode.

sendText

Send text data

Sends text data.

Syntax `public void sendText(String text)` throws **PrinterException**

Parameter	<i>text</i>	Text data to send to the printer Data size that can be specified at 1 time is 16 KB (16384 bytes).
-----------	-------------	---

Exception	<p>PrinterException</p> <p>PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.</p> <p>When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.</p>
-----------	--

Description	This method encodes the specified text data to printable text data based on <code>setInternationalCharacter</code> and <code>setCodePage</code> , and then sends it to the printer.
-------------	---

This method does not add a line feed code at the end of the text data. In order to print to the end, add a line feed code to the end of the text data.

sendTextEx

Send format specified text data

Sends format specified text data to the printer.

The method of syntax (a) or (c) outputs the pending data at first and starts processing.

The method of syntax (b) starts processing according to the constants of the pending data output specifying.

Syntax (a) public void **sendTextEx**(String *text*,
CharacterBold *bold*,
CharacterUnderline *underline*,
CharacterReverse *reverse*,
CharacterFont *font*,
CharacterScale *scale*,
PrintAlignment *alignment*) throws **PrinterException**

(b) public void **sendTextEx**(String *text*,
CharacterBold *bold*,
CharacterUnderline *underline*,
CharacterReverse *reverse*,
CharacterFont *font*,
CharacterScale *scale*,
PrintAlignment *alignment*,
OutputPendingData *output*) throws **PrinterException**

(c) public void **sendTextEx**(String *text*,
CharacterBold *bold*,
CharacterUnderline *underline*,
CharacterReverse *reverse*,
CharacterInversion *inversion*,
CharacterFont *font*,
CharacterScale *scale*,
PrintAlignment *alignment*) throws **PrinterException**

Parameter	<i>text</i>	Text data to send to the printer Data size that can be specified at 1 time is 16 KB (16384 bytes).
	<i>bold</i>	Bold print See "4.2.1(3)③ Bold print (CharacterBold)" for available constants.
	<i>underline</i>	Underline See "4.2.1(3)④ Underline (CharacterUnderline)" for available constants.
	<i>reverse</i>	Reverse print See "4.2.1(3)⑤ Reverse print (CharacterReverse)" for available constants.
	<i>inversion</i>	Inversion print See "4.2.1(3)⑥ Inversion print (CharacterInversion)" for available constants.
	<i>font</i>	Font See "4.2.1(3)⑦ Character font (CharacterFont)" for available constants.
	<i>scale</i>	Character scale See "4.2.1(3)⑧ Character scale (CharacterScale)" for available constants.
	<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.
	<i>output</i>	Pending data output specifying See "4.2.1(3)⑩ Pending data output specifying (OutputPendingData)" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "4.2.5 **PrinterException Class**" for details of the error.
When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

Description This method encodes the specified text data to printable text data based on **setInternationalCharacter** and **setCodePage**, and then sends it to the printer.

For laying out text data by sending following printer commands with **sendBinary** or **sendDataFile**, specify **PENDING_DATA_OUTPUT_TOGETHER** at *output* in the method of syntax (b).

- "Horizontal Tab"
- "Specify Absolute Position"
- "Specify Relative Position"

When the method of syntax (a) is executed or **PENDING_DATA_OUTPUT_FIRST** is specified at *output* in the method of syntax (b), the print position set in above becomes invalid.

This method does not add a line feed code at the end of the text data. In order to print to the end, add a line feed code to the end of the text data.

Prints barcode.

The method of syntax (a) specifies the barcode data by character string.

The method of syntax (b) specifies the barcode data by character string and specifies the alignment and N:W ratio of the barcode.

The method of syntax (c) specifies the barcode data by the array of bytes and specifies the alignment of the barcode.

Syntax (a) public void **printBarcode**(BarcodeSymbol *barcodeSymbol*,
String *text*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*,
PrintAlignment *alignment*) throws **PrinterException**

(b) public void **printBarcode**(BarcodeSymbol *barcodeSymbol*,
String *text*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*,
PrintAlignment *alignment*,
NwRatio *nwRatio*) throws **PrinterException**

(c) public void **printBarcode**(BarcodeSymbol *barcodeSymbol*,
byte[] *data*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*,
PrintAlignment *alignment*) throws **PrinterException**

Parameter	<i>barcodeSymbol</i>	Barcode symbol See "4.2.1(3)⑪ Barcode symbol (BarcodeSymbol)" for available constants and corresponding syntax.
	<i>text (data)</i>	Barcode data to send to the printer
	<i>moduleSize</i>	Barcode width See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>moduleHeight</i>	Barcode height (dot)

- When *barcodeSymbol* is set to the following, the valid range is 1 to 255.

BARCODE_SYMBOL_UPC_A
BARCODE_SYMBOL_UPC_E
BARCODE_SYMBOL_EAN13
BARCODE_SYMBOL_JAN13
BARCODE_SYMBOL_EAN8
BARCODE_SYMBOL_JAN8
BARCODE_SYMBOL_CODE39
BARCODE_SYMBOL_CODE93
BARCODE_SYMBOL_CODE128
BARCODE_SYMBOL_ITF
BARCODE_SYMBOL_CODABAR
BARCODE_SYMBOL_EAN13_ADDON
BARCODE_SYMBOL_JAN13_ADDON

- When *barcodeSymbol* is set to the following, the valid range is different by *barcodeSymbol* and *moduleSize*.

<i>barcodeSymbol</i>		
	<i>moduleSize</i>	Valid Range
BARCODE_SYMBOL_GS1_OMNI_DIRECTIONAL		
	BARCODE_MODULE_WIDTH_2	66 to 255
	BARCODE_MODULE_WIDTH_3	99 to 255
	BARCODE_MODULE_WIDTH_4	132 to 255
	BARCODE_MODULE_WIDTH_5	165 to 255
	BARCODE_MODULE_WIDTH_6	198 to 255
BARCODE_SYMBOL_GS1_TRUNCATED		
	BARCODE_MODULE_WIDTH_2	26 to 255
	BARCODE_MODULE_WIDTH_3	39 to 255
	BARCODE_MODULE_WIDTH_4	52 to 255
	BARCODE_MODULE_WIDTH_5	65 to 255
	BARCODE_MODULE_WIDTH_6	78 to 255
BARCODE_SYMBOL_GS1_LIMITED		
	BARCODE_MODULE_WIDTH_2	20 to 255
	BARCODE_MODULE_WIDTH_3	30 to 255
	BARCODE_MODULE_WIDTH_4	40 to 255
	BARCODE_MODULE_WIDTH_5	50 to 255
	BARCODE_MODULE_WIDTH_6	60 to 255
BARCODE_SYMBOL_GS1_EXPANDED		
	BARCODE_MODULE_WIDTH_2	68 to 255
	BARCODE_MODULE_WIDTH_3	102 to 255
	BARCODE_MODULE_WIDTH_4	136 to 255
	BARCODE_MODULE_WIDTH_5	170 to 255
	BARCODE_MODULE_WIDTH_6	204 to 255

<i>hriPosition</i>	HRI character print position See "4.2.1(3)⑬ HRI character print position (HriPosition)" for available constants.
<i>hriFont</i>	HRI character font See "4.2.1(3)⑦ Character font (CharacterFont)" for available constants.
<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.

nwRatio

N:W ratio

See "4.2.1(3)¹⁴ N:W ratio (NwRatio)" for available constants.

Depending on specified *nwRatio* and *moduleSize*, the wide element width is set as shown in the following table.

<i>moduleSize</i>	<i>nwRatio</i>		
	NWRATIO_ 1TO2	NWRATIO_ 1TO2_5	NWRATIO_ 1TO3
BARCODE_MODULE_WIDTH_2	0.500 mm (4 dots)	0.625 mm (5 dots)	0.750 mm (6 dots)
BARCODE_MODULE_WIDTH_3	0.750 mm (6 dots)	1.000 mm (8 dots)	1.125 mm (9 dots)
BARCODE_MODULE_WIDTH_4	1.000 mm (8 dots)	1.250 mm (10 dots)	1.500 mm (12 dots)
BARCODE_MODULE_WIDTH_5	1.250 mm (10 dots)	1.625 mm (13 dots)	1.875 mm (15 dots)
BARCODE_MODULE_WIDTH_6	1.500 mm (12 dots)	1.875 mm (15 dots)	2.250 mm (18 dots)

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called.

See "4.2.5 **PrinterException Class**" for details of the error.

When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

Note The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.

printPDF417

Print PDF417

Prints PDF417.

The method of syntax (a) specifies PDF417 symbol.

The method of syntax (b) is fixed to standard PDF417.

Syntax (a) public void **printPDF417**(String *text*,
ErrorCorrection *errorCorrection*,
int *row*,
int *column*,
ModuleSize *moduleSize*,
int *moduleHeight*,
PrintAlignment *alignment*,
Pdf417Symbol *pdf417Symbol*) throws **PrinterException**

(b) public void **printPDF417**(String *text*,
ErrorCorrection *errorCorrection*,
int *row*,
int *column*,
ModuleSize *moduleSize*,
int *moduleHeight*,
PrintAlignment *alignment*) throws **PrinterException**

Parameter *text* Barcode data to send to the printer

errorCorrection Error correction level
See "4.2.1(3)¹⁵ Error correction level (ErrorCorrection)" for available constants.

<i>row</i>	<p>The number of rows (row)</p> <p>The valid range is 0, 3 to 90.</p> <p>When 0 is specified, the number of rows is automatically set.</p>
<i>column</i>	<p>The number of columns in data area</p> <p>The valid range is 0 to 30.</p> <p>When 0 is specified, the number of columns in the data area is automatically set.</p>
<i>moduleSize</i>	<p>Nominal fine element width</p> <p>See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.</p>
<i>moduleHeight</i>	<p>Module height (dot)</p> <p>The valid range is 2 to 127.</p> <p>When the module height is set smaller, some barcode scanners may not read it. Set 3 or more for normal use.</p>
<i>alignment</i>	<p>Alignment</p> <p>See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.</p>
<i>pdf417Symbol</i>	<p>Symbol of PDF417</p> <p>See "4.2.1(3)⑩ PDF417 symbol (Pdf417Symbol)" for available constants.</p>
Exception	<p>PrinterException</p> <p>PrinterException is thrown when an error occurs while this method is being called.</p> <p>See "4.2.5 PrinterException Class" for details of the error.</p> <p>When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.</p>
Note	<p>The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.</p>

printQRcode

Print QR Code

Prints QR Code.

The method of syntax (a) is fixed to QR Code Model 2.

The method of syntax (b) specifies QR Code Model.

Syntax	<p>(a) public void printQRcode(String <i>text</i>, ErrorCorrection <i>errorCorrection</i>, ModuleSize <i>moduleSize</i>, PrintAlignment <i>alignment</i>) throws PrinterException</p> <p>(b) public void printQRcode(String <i>text</i>, ErrorCorrection <i>errorCorrection</i>, ModuleSize <i>moduleSize</i>, PrintAlignment <i>alignment</i>, QrModel <i>model</i>) throws PrinterException</p>
Parameter	<p><i>text</i> Barcode data to send to the printer</p> <p>The version for either syntax (a) or (b) is automatically set depending on the number of data specified on <i>text</i>.</p> <p><i>errorCorrection</i> Error correction level</p> <p>See "4.2.1(3)⑮ Error correction level (ErrorCorrection)" for available constants.</p>

<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.
<i>model</i>	QR Code Model See "4.2.1(3)⑰ QR Code Model (QrModel)" for available constants.

Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.
Note	The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.

printDataMatrix Print Data Matrix

Prints Data Matrix.

Syntax	public void printDataMatrix (String <i>text</i> , DataMatrixModule <i>dataMatrixModule</i> , ModuleSize <i>moduleSize</i> , PrintAlignment <i>alignment</i>) throws PrinterException	
Parameter	<i>text</i>	Barcode data to send to the printer
	<i>dataMatrixModule</i>	The number of Data Matrix modules See "4.2.1(3)⑱ Data Matrix module (DataMatrixModule)" for available constants.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.	
Note	The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.	

printMaxiCode Print MaxiCode

Prints MaxiCode.

Syntax	public void printMaxiCode (String <i>text</i> , MaxiCodeMode <i>maxiCodeMode</i> , PrintAlignment <i>alignment</i>) throws PrinterException	
Parameter	<i>text</i>	Barcode data to send to the printer

- When *maxiCodeMode* is **MAXI_CODE_2**
Add the service class (3 digits), the country code (3 digits), and the postal code (9 digits) to the beginning of the data.
- When *maxiCodeMode* is **MAXI_CODE_3**
Add the service class (3 digits), the country code (3 digits), and the postal code (6 digits) to the beginning of the data.

```
printGS1DataBarStacked
```

Prints GS1 Databar Stacked.

printGS1DataBarStackedOmnidirectional

Prints GS1 Databar Stacked Omni-directional.

Parameter	<i>text</i>	Barcode data to send to the printer Enter 13 characters from '0' to '9'. The leading '01' is automatically added by the printer. The check digit is automatically calculated by the printer.
	<i>moduleHeight</i>	Barcode module height (the number of the modules) The valid range is 33 to 255.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.
Exception	PrinterException	PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.

printGS1DataBarExpandedStacked

Print GS1 Databar Expanded Stacked

Prints GS1 Databar Expanded Stacked.

Syntax	public void printGS1DataBarExpandedStacked (String <i>text</i> , int <i>column</i> , ModuleSize <i>moduleSize</i> , PrintAlignment <i>alignment</i>) throws PrinterException	
Parameter	<i>text</i>	Barcode data to send to the printer Enter any number of characters using the following: ' ', '!', '"', '%', '&', '(', ')', '*', '+', ',', '-', '.', '/', ':', ';', '<', '=', '>', '?', '_ ', '0' to '9', 'A' to 'Z', 'a' to 'z'. Enter '{1' to FNC1. Be sure to input the check digit because it is not automatically calculated by the printer.
	<i>column</i>	The number of columns Specifies the number of the segments in 1 line. The valid range is the even number from 2 to 20.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>alignment</i>	Alignment See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.
Exception	PrinterException	PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.

Syntax public void **printAztecCode**(String *text*,
 int *layer*,
 int *errorCorrection*,
 ModuleSize *moduleSize*,
 AztecSymbol *aztecSymbol*,
 PrintAlignment *alignment*) throws **PrinterException**

Parameter	<i>text</i>	Barcode data to send to the printer Encodes the data to binary in UTF-8 and sends to the printer. When the data to be sent cannot be specified as a string, it can be specified using the following escape sequence.
-----------	-------------	--

Escape Sequence	Description
\u00nn	Control code (Specify nn as a hexadecimal number)
\\	Backslash

To specify FNC1, enter "\u001b\u0030" in the data.
To specify 1Bh, enter "\u001b\u001b" in the data.

<i>layer</i>	Number of layer The valid range of full-range mode is 0, 4 to 32. The valid range of compact mode is 0, 1 to 4. When 0 is specified, layer is set automatically.
--------------	---

<i>errorCorrection</i>	Error correction level (%) The valid range is 0, 5 to 95. When 0 is specified, the level is set to 23%.
------------------------	---

<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
-------------------	--

aztecSymbol Aztec symbol
See "4.2.1(3) Aztec Symbol (AztecSymbol)" for available constants.

alignment Alignment
See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.

Exception	<p>PrinterException</p> <p>PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.</p> <p>When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.</p>
-----------	--

Feeds the paper to the paper cut position. The paper is not cut.

Syntax	public void cutPaper (CuttingMethod <i>cuttingMethod</i>) throws PrinterException	
Parameter	<i>cuttingMethod</i>	Cutting method See "4.2.1(3)② Cutting method (CuttingMethod)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.	

Supported only by MP-B30L.
Performs the paper form feed of marked paper or label.

Syntax	public void feedPosition (FeedPosition <i>feedPosition</i>) throws PrinterException	
Parameter	<i>feedPosition</i>	Form feed position See "4.2.1(3)② Form feed position (FeedPosition)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.	
Note	The paper form feed is not performed when this method is executed at the form feed position of the marked paper or the label.	

Sends binary data to the printer.

Syntax	public void sendBinary (byte [] <i>binary</i>) throws PrinterException	
Parameter	<i>binary</i>	Binary data to send to the printer Data size that can be specified at 1 time is 16 KB (16384 bytes).
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.	
Description	This method sends the specified binary data to the printer without conversion. By sending printer commands as binary data with this method, printer functions which are not supported in the library become available. However, this method does not support commands which get responses from the printer.	

Sends file data.

The method of syntax (a), dithering is fixed to be disabled.

The method of syntax (b), dithering can be specified.

Syntax (a) public void **sendDataFile**(String *fileName*,
PrintAlignment *alignment*) throws **PrinterException**

(b) public void **sendDataFile**(String *fileName*,
PrintAlignment *alignment*,
Dithering *dithering*) throws **PrinterException**

Parameter	<i>fileName</i>
-----------	-----------------

Name of the data file to send to the printer

The formats that can be entered are described below.

- Absolute path string handled by Java standard class "java.io.File"
When targeting Android 10 (API 29) or later, please note that some files cannot be handled directly.
See "3.5 Precautions - About Scoped Storage" for details.

- URI string of the following scheme name handled by the class "android.net.Uri" prepared for Android
 - file://
 - content://

It is necessary to specify the URI string obtained from "Storage Access Framework" for this parameter. Please note that URI created without being obtained from "Storage Access Framework" may not be able to open the file.

The maximum file size that can be specified is 1 MB (1048576 bytes).

The file extensions that can be sent and the file transmission are described below.

- .bmp, .jpg, .jpeg, .png

Data is sent to the printer as image file. Colored image file is converted to monochrome image by binarization and registered. Printing is performed at one time after mapping the image file in memory of the printer.

- .txt

Data is sent to the printer as text data. Text data format supports UTF-8. This method encodes the text data to printable text data based on the settings of `setInternationalCharacter` and `setCodePage`, and then sends it to the printer.

This method does not add a line feed code at the end of the text data. In order to print to the end, add a line feed code to the end of the text data.

- .bin. .dat

Data is sent to the printer as the binary data without conversion.

alignment

Alignment

The alignment is valid only when the file extension specified on *fileName* is .bmp, .jpg, .jpeg, .png, or .txt.

See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.

dithering Dithering
The dithering is valid only when the file extension specified on *fileName* is .bmp, .jpg, .jpeg, or .png.
See "4.2.1(3)① Dithering (Dithering) " for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.
When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

printLogo	Print logo
------------------	------------

Prints the registered logo.

Syntax public void **printLogo**(String *id*, PrintAlignment *alignment*) throws **PrinterException**


Parameter *id* Logo ID to print (key code)
Specify the ID of the registered logo as a character string.

alignment Alignment
See "4.2.1(3)⑨ Alignment (PrintAlignment)" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.
When the data transmission is failed, the communication with the printer is ended, and **PrinterException** may be thrown. See **isConnect** for verifying the connection state with the printer.

③ Dedicated method for page mode

The following methods are dedicated methods to use page mode. An example for the print process in page mode is shown below.



① Start page mode

```
mPrinterManager.enterPageMode();
```

② Specify print area of page mode

```
mPrinterManager.setPageModeArea(0, 0, 576, 355);
```

③ Specify a rectangle and a ruled line

```
mPrinterManager.printPageModeRectangle(0, 0, 575, 344, LineStyle.LINESTYLE_THIN);  
mPrinterManager.printPageModeRectangle(7, 7, 567, 336, LineStyle.LINESTYLE_THIN);  
mPrinterManager.printPageModeLine(404, 11, 404, 334, LineStyle.LINESTYLE_THIN);
```

④ Specify a character

```
mPrinterManager.printPageModeText(21, 37, "NO.123456789");  
mPrinterManager.printPageModeText(212, 330, "Date 2020-01-01");
```

⑤ Specify an image file

```
mPrinterManager.printPageModeImageFile(  
    10,  
    212,  
    Environment.getExternalStorageDirectory().getPath() + "/TicketImage.jpg",  
    Dithering.DITHERING_DISABLE);
```

⑥ Specify print area of page mode

```
mPrinterManager.setPageModeArea(404, 0, 163, 345);
```

⑦ Specify print direction

```
mPrinterManager.setPageModeDirection(Direction.DIRECTION_BOTTOM_TO_TOP);
```

⑧ Specify a barcode

```
mPrinterManager.printPageModeBarcode(  
    20,  
    132,  
    BarcodeSymbol.BARCODE_SYMBOL_CODE128,  
    new byte[]{0x67, 0x11, 0x12, 0x13, 0x14, 0x15, 0x16, 0x17, 0x18, 0x19x, 0x68},  
    ModuleSize.BARCODE_MODULE_WIDTH_2,  
    80,  
    HriPosition.HRI_POSITION_ABOVE,  
    CharacterFont.FONT_A);
```

⑨ Print in page mode

```
mPrinterManager.printPageMode(CuttingMethod.CUT_PARTIAL);
```

⑩ Ends page mode

```
mPrinterManager.exitPageMode();
```

enterPageMode

Start page mode

Starts page mode.

Syntax public void **enterPageMode()** throws **PrinterException**

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description This method starts page mode. The dedicated method for page mode and common methods to standard mode and page mode can be used after this method execution.

Executing **exitPageMode** discards the print data kept in the page data buffer and changes the mode to standard mode.

Executing **printPageMode** prints the print data kept in the page data buffer.

exitPageMode

End page mode

Ends page mode and changes the mode to standard mode.

Syntax public void **exitPageMode()** throws **PrinterException**

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Discards the print data kept in the page data buffer and changes the mode to standard mode.

setPageModeArea

Specify print area of page mode

Specifies print area of page mode.

Syntax public void **setPageModeArea**(int *x*,
 int *y*,
 int *width*,
 int *height*) throws **PrinterException**


Parameter *x* The horizontal origin (dot) of the print area of page mode
 The valid range is 0 to 575.
 0 represents the left edge on the print area of the printer.

y The vertical origin (dot) of the print area of page mode
 The valid range is 0 to 2399.
 0 represents the position where paper feed has not been performed.

width The print area width (dot) of page mode
 The valid range is 1 to (576-*x*).

height The print area height (dot) of page mode
 The valid range is 1 to (2400-*y*).

The relation between the print area of page mode and the print area of the printer is shown in figure below.



Exception `PrinterException`

`PrinterException` is thrown when an error occurs while this method is being called. See "**4.2.5 `PrinterException` Class**" for details of the error.

Description Start page mode by **`enterPageMode`** before executing this method.

Starting page mode by **`enterPageMode`** and executing this method after the dedicated method for page mode is executed, the print area of page mode can be additionally specified. The data that has been mapped is kept.

The data of the dedicated method for page mode is mapped to the print area of page mode added by this method after executing this method.

The print area of page mode is $x = 0$, $y = 0$, $width = 576$, $height = 2400$ after executing **`enterPageMode`**.

setPageModeDirection

Specify print direction of page mode

Specifies print direction of page mode.

Syntax	public void setPageModeDirection (Direction <i>direction</i>) throws PrinterException	
Parameter	<i>direction</i>	Print direction See "4.2.1(3)㉓ Print direction (Direction)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error.	
Description	Start page mode by enterPageMode before executing this method. The print direction is left to right after executing enterPageMode .	

setPageModeLineSpacing

Specify line spacing of page mode

Specifies line spacing of page mode.

Syntax	public void setPageModeLineSpacing (int <i>lineSpacing</i>) throws PrinterException	
Parameter	<i>linespacing</i>	Line spacing (dot) of page mode The valid range is 0 to 255.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error.	
Description	Start page mode by enterPageMode before executing this method. The line spacing is 34 dots after executing enterPageMode .	

printPageMode

Print page mode

Prints the print data kept in page data buffer.

Syntax	public void printPageMode (CuttingMethod <i>cuttingMethod</i>) throws PrinterException	
Parameter	<i>cuttingMethod</i>	Cutting method See "4.2.1(3)㉑ Cutting method (CuttingMethod)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error. When the data transmission is failed, the communication with the printer is ended, and PrinterException may be thrown. See isConnect for verifying the connection state with the printer.	
Description	The print data is kept after printing. The print data is discarded at the timing of the following: <ul style="list-style-type: none">•Execute enterPageMode•Execute disconnect•Execute exitPageMode	

Maps the text data on the print area of page mode.

Syntax	public void printPageModeText (int <i>startX</i> , int <i>startY</i> , String <i>text</i>) throws PrinterException	
Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Text data Data size that can be specified at 1 time is 16 KB (16384 bytes).
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class " for details of the error.	
Description	This method encodes the specified text data to printable text data based on setInternationalCharacter and setCodePage . Start page mode by enterPageMode before executing this method.	

Maps the format specified text data on the print area of page mode.

Syntax	public void printPageModeTextEx (int <i>startX</i> , int <i>startY</i> , String <i>text</i> , CharacterBold <i>bold</i> , CharacterUnderline <i>underline</i> , CharacterReverse <i>reverse</i> , CharacterFont <i>font</i> , CharacterScale <i>scale</i>) throws PrinterException	
Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Text data Data size that can be specified at 1 time is 16 KB (16384 bytes).
	<i>bold</i>	Bold print See "4.2.1(3)③ Bold print (CharacterBold)" for available constants.
	<i>underline</i>	Underline See "4.2.1(3)④ Underline (CharacterUnderline)" for available constants.
	<i>reverse</i>	Reverse print See "4.2.1(3)⑤ Reverse print (CharacterReverse)" for available constants.
	<i>font</i>	Font See "4.2.1(3)⑦ Character font (CharacterFont)" for available constants.

scale Character scale
See "4.2.1(3)⑧ Character scale (CharacterScale)" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description This method encodes the specified text data to printable text data based on **setInternationalCharacter** and **setCodePage**.

Start page mode by **enterPageMode** before executing this method.

printPageModeBarcode

Print barcode of page mode

Maps the barcode on the print area of page mode.

The method of syntax (a) specifies the barcode data by character string.

The method of syntax (b) specifies the barcode data by character string and specifies N:W ratio of the barcode.

The method of syntax (c) specifies the barcode data by the array of bytes.

Syntax (a) public void **printPageModeBarcode**(int *startX*,
int *startY*,
BarcodeSymbol *barcodeSymbol*,
String *text*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*) throws **PrinterException**

(b) public void **printPageModeBarcode**(int *startX*,
int *startY*,
BarcodeSymbol *barcodeSymbol*,
String *text*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*,
NwRatio *nwRatio*) throws **PrinterException**

(c) public void **printPageModeBarcode**(int *startX*,
int *startY*,
BarcodeSymbol *barcodeSymbol*,
byte[] *data*,
ModuleSize *moduleSize*,
int *moduleHeight*,
HriPosition *hriPosition*,
CharacterFont *hriFont*) throws **PrinterException**

Parameter *startX* The horizontal reference point (dot) from the starting point
The valid range is 0 to 2399.

startY The vertical reference point (dot) from the starting point
The valid range is 0 to 2399.

barcodeSymbol BarcodeSymbol
See "4.2.1(3)⑪ Barcode symbol (BarcodeSymbol) for available constants and correspondent syntax.

text(data) Barcode data

moduleSize Barcode width
See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.

moduleHeight Barcode height (dot)

- When *barcodeSymbol* is set to the following, the valid range is 1 to 255.

BARCODE_SYMBOL_UPC_A
 BARCODE_SYMBOL_UPC_E
 BARCODE_SYMBOL_EAN13
 BARCODE_SYMBOL_JAN13
 BARCODE_SYMBOL_EAN8
 BARCODE_SYMBOL_JAN8
 BARCODE_SYMBOL_CODE39
 BARCODE_SYMBOL_CODE93
 BARCODE_SYMBOL_CODE128
 BARCODE_SYMBOL_ITF
 BARCODE_SYMBOL_CODABAR
 BARCODE_SYMBOL_EAN13_ADDON
 BARCODE_SYMBOL_JAN13_ADDON

- When *barcodeSymbol* is set to the following, the valid range is different by *barcodeSymbol* and *moduleSize*.

<i>barcodeSymbol</i>		
	<i>moduleSize</i>	Valid Range
BARCODE_SYMBOL_GS1_OMNI_DIRECTIONAL		
	BARCODE_MODULE_WIDTH_2	66 to 255
	BARCODE_MODULE_WIDTH_3	99 to 255
	BARCODE_MODULE_WIDTH_4	132 to 255
	BARCODE_MODULE_WIDTH_5	165 to 255
	BARCODE_MODULE_WIDTH_6	198 to 255
BARCODE_SYMBOL_GS1_TRUNCATED		
	BARCODE_MODULE_WIDTH_2	26 to 255
	BARCODE_MODULE_WIDTH_3	39 to 255
	BARCODE_MODULE_WIDTH_4	52 to 255
	BARCODE_MODULE_WIDTH_5	65 to 255
	BARCODE_MODULE_WIDTH_6	78 to 255
BARCODE_SYMBOL_GS1_LIMITED		
	BARCODE_MODULE_WIDTH_2	20 to 255
	BARCODE_MODULE_WIDTH_3	30 to 255
	BARCODE_MODULE_WIDTH_4	40 to 255
	BARCODE_MODULE_WIDTH_5	50 to 255
	BARCODE_MODULE_WIDTH_6	60 to 255
BARCODE_SYMBOL_GS1_EXPANDED		
	BARCODE_MODULE_WIDTH_2	68 to 255
	BARCODE_MODULE_WIDTH_3	102 to 255
	BARCODE_MODULE_WIDTH_4	136 to 255
	BARCODE_MODULE_WIDTH_5	170 to 255

<i>barcodeSymbol</i>		
	<i>moduleSize</i>	Valid Range
	BARCODE_MODULE_WIDTH_6	204 to 255

- hriPosition* HRI character print position
See "4.2.1(3)⑬ HRI character print position (HriPosition)" for available constants.
- hriFont* HRI character font
See "4.2.1(3)⑦ Character font (CharacterFont)" for available constants.
- nwRatio* N:W ratio
See "4.2.1(3)⑭ N:W ratio (NwRatio)" for available constants.
Depending on specified *nwRatio* and *moduleSize*, the wide element width is set as shown in the following table.

<i>moduleSize</i>	<i>nwRatio</i>		
	NWRATIO_1TO2	NWRATIO_1TO2_5	NWRATIO_1TO3
BARCODE_MODULE_WIDTH_2	0.500 mm (4 dots)	0.625 mm (5 dots)	0.750 mm (6 dots)
BARCODE_MODULE_WIDTH_3	0.750 mm (6 dots)	1.000 mm (8 dots)	1.125 mm (9 dots)
BARCODE_MODULE_WIDTH_4	1.000 mm (8 dots)	1.250 mm (10 dots)	1.500 mm (12 dots)
BARCODE_MODULE_WIDTH_5	1.250 mm (10 dots)	1.625 mm (13 dots)	1.875 mm (15 dots)
BARCODE_MODULE_WIDTH_6	1.500 mm (12 dots)	1.875 mm (15 dots)	2.250 mm (18 dots)

- Exception** **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.
- Description** Start page mode by **enterPageMode** before executing this method.
- Note** Map the print data of the barcode not to overlap the other print data.
The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.

printPageModePDF417 Print PDF417 of page mode

Maps PDF417 on the print area of page mode.
The method of syntax (a) specifies PDF417 symbol.
The method of syntax (b) is fixed to standard PDF417.

- Syntax** (a) public void **printPageModePDF417**(int *startX*,
int *startY*,
String *text*,
ErrorCorrection *ErrorCorrection*,
int *row*,
int *column*,
ModuleSize *moduleSize*,
int *moduleHeight*,
Pdf417Symbol *pdf417Symbol*) throws **PrinterException**

```
(b) public void printPageModePDF417(int startX,
                                     int startY,
                                     String text,
                                     ErrorCorrection ErrorCorrection,
                                     int row,
                                     int column,
                                     ModuleSize moduleSize,
                                     int moduleHeight) throws PrinterException
```

Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data
	<i>errorCorrection</i>	Error correction level See "4.2.1(3)⑮ Error correction level (ErrorCorrection)" for available constants.
	<i>row</i>	The number of rows (row) The valid range is 0, 3 to 90. When 0 is specified, the number of rows is automatically set.
	<i>column</i>	The number of columns in data area The valid range is 0 to 30. When 0 is specified, the number of columns in the data area is automatically set.
	<i>moduleSize</i>	Nominal fine element width See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>moduleHeight</i>	Module height (dot) The valid range is 2 to 127. When the module height is set smaller, some barcode scanners may not read it. Set 3 or more for normal use.
	<i>pdf417Symbol</i>	Symbol of PDF417 See "4.2.1(3)⑯ PDF417 symbol (Pdf417Symbol)" for available constants.
Exception	PrinterException	PrinterException is thrown when an error occurs while this method is being called. See " 4.2.5 PrinterException Class " for details of the error.
Description	Start page mode by enterPageMode before executing this method.	
Note	Map the print data of the barcode not to overlap the other print data. The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.	

Maps QR Code on the print area of page mode.
 The method of syntax (a) is fixed to QR Code Model 2.
 The method of syntax (b) specifies QR Code Model.

Syntax	(a) public void printPageModeQRcode (int <i>startX</i> , int <i>startY</i> , String <i>text</i> , ErrorCorrection <i>ErrorCorrection</i> , ModuleSize <i>moduleSize</i>) throws PrinterException (b) public void printPageModeQRcode (int <i>startX</i> , int <i>startY</i> , String <i>text</i> , ErrorCorrection <i>ErrorCorrection</i> , ModuleSize <i>moduleSize</i> , QrModel <i>model</i>) throws PrinterException	
Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data The version for either syntax (a) or (b) is automatically set depending on the number of data specified on <i>text</i> .
	<i>errorCorrection</i>	Error correction level See "4.2.1(3)⑮ Error correction level (ErrorCorrection)" for available constants.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
	<i>model</i>	QR Code Model See "4.2.1(3)⑰ QR Code Model (QrModel)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class " for details of the error." for details of the error.	
Description	Start page mode by enterPageMode before executing this method.	
Note	Map the print data of the barcode not to overlap the other print data. The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.	

Maps Data Matrix on the print area of page mode.

Syntax	public void printPageModeDataMatrix (int <i>startX</i> , int <i>startY</i> , String <i>text</i> , DataMatrixModule <i>dataMatrixModule</i> , ModuleSize <i>moduleSize</i>) throws PrinterException	
--------	---	--

Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data
	<i>dataMatrixModule</i>	The number of Data Matrix modules See "4.2.1(3) ¹⁸ Data Matrix module (DataMatrixModule)" for available constants.
	<i>moduleSize</i>	Module size See "4.2.1(3) ¹² Module size (ModuleSize)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.	
Description	Start page mode by enterPageMode before executing this method.	
Note	Map the print data of the barcode not to overlap the other print data. The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.	

printPageModeMaxiCode

Print MaxiCode of page mode

Maps MaxiCode on the print area of page mode.

Syntax	<pre>public void printPageModeMaxiCode(int startX, int startY, String text, MaxiCodeMode maxiCodeMode) throws PrinterException</pre>	
Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data
	<i>maxiCodeMode</i>	<ul style="list-style-type: none"> When <i>maxiCodeMode</i> is MAXI_CODE_2 Add the service class (3 digits), the country code (3 digits), and the postal code (9 digits) to the beginning of the data. When <i>maxiCodeMode</i> is MAXI_CODE_3 Add the service class (3 digits), the country code (3 digits), and the postal code (6 digits) to the beginning of the data.
	<i>maxiCodeMode</i>	MaxiCode Mode See "4.2.1(3) ¹⁹ MaxiCode Mode (MaxiCodeMode)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.	
Description	Start page mode by enterPageMode before executing this method.	

Note Map the print data of the barcode not to overlap the other print data.
The quiet zone is not secured. Set the quiet zone in accordance with the standard of the barcode symbol.

printPageModeGS1DataBarStacked Print GS1 Databar Stacked of page mode

Maps GS1 Databar Stacked on the print area of page mode.

Syntax `public void printPageModeGS1DataBarStacked(int startX,
int startY,
String text,
ModuleSize moduleSize) throws PrinterException`

Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data Enter 13 characters from '0' to '9'. The leading '01' is automatically added by the printer. The check digit is automatically calculated by the printer.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

Note Map the print data of the barcode not to overlap the other print data.

printPageModeGS1DataBarStackedOmnidirectional Print GS1 Databar Stacked Omni-directional of page mode

Maps GS1 Databar Stacked Omni-directional on the print area of page mode.

Syntax `public void printPageModeGS1DataBarStackedOmnidirectional(int startX,
int startY,
String text,
int moduleHeight,
ModuleSize moduleSize) throws PrinterException`

Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data Enter 13 characters from '0' to '9'. The leading '01' is automatically added by the printer. The check digit is automatically calculated by the printer.
	<i>moduleHeight</i>	Barcode module height (the number of the modules) The valid range is 33 to 255.

	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.	
Description	Start page mode by enterPageMode before executing this method.	
Note	Map the print data of the barcode not to overlap the other print data.	

printPageModeGS1DataBarExpandedStacked

Print GS1 Databar Expanded Stacked of page mode

Maps GS1 Databar Expanded Stacked on the print area of page mode.

Syntax	<pre>public void printPageModeGS1DataBarExpandedStacked(int startX, int startY, String text, int column, ModuleSize moduleSize) throws PrinterException</pre>	
Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
	<i>text</i>	Barcode data Enter any number of characters using the following: ' ', '!', '""', '%', '&', '"', '(', ')', '*', '+', ',', '-', '.', '/', ':', ';', '<', '=', '>', '?', '_ ', '0' to '9', 'A' to 'Z', 'a' to 'z'. Enter '{1' to FNC1. Be sure to input the check digit because it is not automatically calculated by the printer.
	<i>column</i>	The number of columns Specifies the number of the segments in 1 line. The valid range is the even number from 2 to 20.
	<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
Exception	PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.	
Description	Start page mode by enterPageMode before executing this method.	
Note	Map the print data of the barcode not to overlap the other print data.	

Maps Aztec Code on the print area of page mode.

Syntax	<pre> public void printPageModeAztecCode(int <i>startX</i>, int <i>startY</i>, String <i>text</i>, int <i>layer</i>, int <i>errorCorrection</i>, ModuleSize <i>moduleSize</i> AztecSymbol <i>aztecSymbol</i>) throws PrinterException </pre>
--------	--

<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
---------------	---

<i>text</i>	Barcode data send to the printer Encodes the data to binary in UTF-8 and sends to the printer. When the data to be sent cannot be specified as a string, it can be specified using the following escape sequence.
-------------	---

Escape Sequence	Description
\u00nn	Control code (Specify nn as a hexadecimal number)
\\	Backslash

To specify FNC1, enter "\u001b\u0030" in the data.
To specify 1Bh, enter "\u001b\u001b" in the data.

<i>layer</i>	Number of layer The valid range of full-range mode is 0, 4 to 32. The valid range of compact mode is 0, 1 to 4. When 0 is specified, layer is set automatically.
--------------	---

<i>errorCorrection</i>	Error correction level (%) The valid range is 0, 5 to 95. When 0 is specified, the level is set to 23%.
------------------------	---

<i>moduleSize</i>	Module size See "4.2.1(3)⑫ Module size (ModuleSize)" for available constants.
-------------------	--

aztecSymbol Aztec symbol
See "4.2.1(3)Ⓢ Aztec Symbol (AztecSymbol)" for available constants.

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
 See "**4.2.5 PrinterException Class**" for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

Note Map the print data of the barcode not to overlap the other print data.

Maps binary data on the print area of page mode.

Syntax public void **sendPageModeBinary**(byte [] *binary*) throws **PrinterException**

Parameter *binary* Binary data
Data size that can be specified at 1 time is 16 KB (16384 bytes).

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

This method sends the specified binary data to the printer without conversion.

By sending printer commands as binary data with this method, printer functions which are not supported in the library become available.

Note This method may execute unexpected performance depending on the data to send. Please ensure the performance with your actual device in advance.

Maps the image file on the print area of page mode.

Syntax public void **printPageModeImageFile**(int *startX*,
 int *startY*,
 String *fileName*,
 Dithering *dithering*) throws **PrinterException**

Parameter *startX* The horizontal reference point (dot) from the starting point
The valid range is 0 to 2399.

startY The vertical reference point (dot) from the starting point
The valid range is 0 to 2399.

fileName Name of the image file
The formats that can be entered are described below.

- Absolute path string handled by Java standard class "java.io.File"
When targeting Android 10 (API 29) or later, please note that some files cannot be handled directly.
See "3.5 Precautions - About Scoped Storage" for details.

- URI string of the following scheme name handled by the class "android.net.Uri" prepared for Android
 - file://
 - content://

It is necessary to specify the URI string obtained from "Storage Access Framework" for this parameter. Please note that URI created without being obtained from "Storage Access Framework" may not be able to open the file.

The maximum file size that can be specified is 1 MB (1048576 bytes).
The image files that can be sent are .bmp, .jpg, .jpeg, .png.
Colored image file is converted to monochrome image by binarization and registered.

Dithering

See "4.2.1(3)① Dithering (Dithering)" for available constants.

Exception **PrinterException**

PrinterException is thrown when an error occurs while this method is being called. See **"4.2.5 PrinterException Class"** for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

printPageModeRectangle

Draw rectangle image of page mode

Maps the rectangle image on the print area of page mode.

```
Syntax      public void printPageModeRectangle(int startX,
                                                int startY,
                                                int endX,
                                                int endY,
                                                LineStyle LineStyle) throws PrinterException
```

Parameter	<i>startX</i>	The horizontal reference point (dot) from the starting point. The valid range is 0 to 2399.
-----------	---------------	--

<i>startY</i>	The vertical reference point (dot) from the starting point The valid range is 0 to 2399.
---------------	---

endX The horizontal reference point (dot) from the ending point.
The valid range is 0 to 2399.

endY The vertical reference point (dot) from the ending point
The valid range is 0 to 2399.


lineStyle Line style
See "4.2.1(3)②④ Line style (LineStyle)" for available constants.

Exception **PrinterException**


PrinterException is thrown when an error occurs while this method is being called. See **"4.2.5 PrinterException Class"** for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

The rectangle is mapped to *direction* of **setPageModeDirection** as shown in the figure below.



The example of the parameter setting to the image is shown below.
Example: Draw a square with a medium solid line (4 dots) at 240 dots (30 mm) from the starting point.

Image	Parameter
 <p>The diagram illustrates a square drawn on a coordinate system. The starting point is labeled $(startX=0, startY=0)$ at the top-left corner. The ending point is labeled $(endX=239, endY=239)$ at the bottom-right corner. The square is drawn with a medium solid line, indicated by the text <code>lineStyle= LINESTYLE_MEDIUM (4 dots)</code> inside the square. Arrows point from the text to the corresponding corners of the square.</p>	<pre>startX 0 startY 0 endX 239 endY 239 lineStyle LINESTYLE_MEDIUM</pre>


printPageModeLine

Print ruled line of page mode

Maps the ruled line on the print area of page mode.

Syntax	<pre>public void printPageModeLine(int <i>startX</i>, int <i>startY</i>, int <i>endX</i>, int <i>endY</i>, LineStyle <i>LineStyle</i>) throws PrinterException</pre>
Parameter	<p><i>startX</i> The horizontal reference point (dot) from the starting point The valid range is 0 to 2399.</p> <p><i>startY</i> The vertical reference point (dot) from the starting point The valid range is 0 to 2399.</p> <p><i>endX</i> The horizontal reference point (dot) from the ending point The valid range is 0 to 2399.</p> <p><i>endY</i> The vertical reference point (dot) from the ending point The valid range is 0 to 2399.</p> <p><i>lineStyle</i> Line style See "4.2.1(3)④ Line style (LineStyle)" for available constants.</p>
Exception	<p>PrinterException PrinterException is thrown when an error occurs while this method is being called. See "4.2.5 PrinterException Class" for details of the error.</p>
Description	<p>Start page mode by enterPageMode before executing this method.</p> <p>A diagonal stroke cannot be drawn by this method.</p>

The ruled line is mapped to the *direction* of **setPageModeDirection** as shown in the figure below.



Mapping direction of horizontal ruled line Mapping direction of vertical ruled line

The setting example of the parameter to the image is shown below.

Example: Draw a horizontal ruled line of a square with a medium solid line (4 dots) at 240 dots (30 mm) from the starting point.

Image	Parameter
	<p>①</p> <pre> startX 0 startY 0 endX 239 endY 0 lineStyle LINESYLE_MEDIUM </pre> <p>②</p> <pre> startX 0 startY 236 endX 239 endY 236 lineStyle LINESYLE_MEDIUM </pre>

Example: Draw a vertical ruled line of a square with a medium solid line (4 dots) at 240 dots (30 mm) from the starting point.

Image	Parameter
	<p>①</p> <pre> startX 0 startY 0 endX 0 endY 239 lineStyle LINESYLE_MEDIUM </pre> <p>②</p> <pre> startX 236 startY 0 endX 236 endY 239 lineStyle LINESYLE_MEDIUM </pre>

Maps the registered logo on the print area of page mode.

Syntax public void **printPageModeLogo**(int *startX*, int *startY*, String *id*) throws **PrinterException**

Parameter *startX* The horizontal reference point (dot) from the starting point
The valid range is 0 to 2399.

startY The vertical reference point (dot) from the starting point
The valid range is 0 to 2399.

id Logo ID to print (key code)
Specify the ID of the registered logo as a character string

Exception **PrinterException**
PrinterException is thrown when an error occurs while this method is being called.
See "**4.2.5 PrinterException Class**" for details of the error.

Description Start page mode by **enterPageMode** before executing this method.

4.2.2 PrinterEvent Class

PrinterEvent class gets the end event that occurs when **startDiscoveryPrinter** is terminated.

(1) Method List

Methods provided by the **PrinterEvent** class are shown in the following table.

Name	Description
getEventType	Get end event

(2) End event constant

Constants used for getting the end event are shown in the following table.

Constant Name	Description	Value
EVENT_FINISHED_DISCOVERY	Completion of startDiscoveryPrinter	1
EVENT_CANCELED_DISCOVERY	Cancellation by cancelDiscoveryPrinter	2

(3) Method Details

getEventType	Get end event
---------------------	---------------

Gets the end event when **startDiscoveryPrinter** is terminated.

Syntax `public int getEventType()`

Return value See "4.2.2(2) End event constant" for details of the value.

Description Whether **startDiscoveryPrinter** has been completed or the search has been canceled by **cancelDiscoveryPrinter** can be determined by the end event.
Even when the printer was not discovered, **EVENT_FINISHED_DISCOVERY** is returned.

4.2.3 PrinterListener Interface

PrinterListener interface is for getting the end event when **startDiscoveryPrinter** is terminated.

(1) Method List

Methods of the **PrinterListener** interface are shown in the following table.

Name	Description
finishEvent	End event of printer search

(2) Method Details

finishEvent	End event of printer search
--------------------	-----------------------------

End event that is called when **startDiscoveryPrinter** is completed, or when **cancelDiscoveryPrinter** is executed.

Syntax `public void finishEvent(PrinterEvent event)`

Parameter *event* End event
It is specified by **PrinterEvent** class.

Description This method is an interface, so it is not implemented.
Implement this method in the user application that receives the notification of the end event by completion of **startDiscoveryPrinter** or cancellation by **cancelDiscoveryPrinter**. Determine the type of the end event by **getEventType** in **PrinterEvent** class.

4.2.4 PrinterInfo Class

PrinterInfo class stores the information of the printer found by **startDiscoveryPrinter**.

(1) Method List

Printer model name (Bluetooth device name), Bluetooth address, MAC address, IP address, port name (device path) and pairing status can be retrieved. Methods of **PrinterInfo** class are shown in the following table.

Name	Description
getPrinterModelName	Get printer model name
getBluetoothAddress	Get Bluetooth address
getMacAddress	Get MAC address
getIpAddress	Get IP address
getIsBonded	Get pairing status
getDevicePath	Get device path

(2) Method Details

getPrinterModelName Get printer model name

Gets the character string of the printer model name (Bluetooth device name) from the printer information found by **startDiscoveryPrinter**.

Syntax `public String getPrinterModelName()`

Return value Printer model name (Bluetooth device name)

getBluetoothAddress Get Bluetooth address

Gets the character string of the Bluetooth address from the printer information found by **startDiscoveryPrinter**.

Syntax `public String getBluetoothAddress()`

Return value Bluetooth address

getMacAddress Get MAC address

Gets the character string of the MAC address from the printer information found by **startDiscoveryPrinter**.

Syntax `public String getMacAddress()`

Return value MAC address

getIPAddress

Get IP address

Gets the character string of the IP address from the printer information found by **startDiscoveryPrinter**.

Syntax public String **getIpAddress()**

Return value IP address

getIsBonded

Get pairing status

Gets the status of pairing from the printer information found by **startDiscoveryPrinter**.

Syntax public boolean **getIsBonded()**

Return value true Paired
 false Not paired

getDevicePath

Get device path

Gets the character string of the USB device file path from the printer information found by **startDiscoveryPrinter**.

Syntax public String **getDevicePath()**

Return value Device path

4.2.5 PrinterException Class

(1) Method List

Methods provided by the **PrinterException** class are shown in the following table.

Name	Description
PrinterException	Constructor
getErrorCode	Get error code

(2) Constant List

① Error code

Constants used for getting error codes are shown in following table.

Constant Name	Description	Value
ERROR_ACCESS_DENIED	Failed to get the handle.* ¹	-1
	Unavailable port is specified.	
	Unsupported method is specified.	
ERROR_SHARING_VIOLATION	Already opened port is specified.	-11
ERROR_PORT_NOT_OPENED	Port is not opened.	-12
ERROR_DEVICE_NOT_CONNECTED	There is a problem with Bluetooth connection between the Android device and printer.	-21
	There is a problem with USB connection between the Android device and printer.	
ERROR_DEVICE_INITIALIZE_FAILED	Failed to change the printer setting. Data sending to the printer is not completed within the send timeout period, or data receiving from the printer is not completed within the receive timeout period.	-31
ERROR_DATA_SIZE_ZERO	0-byte data has been specified.	-101
ERROR_OVER_MAX_DATA_SIZE	Maximum data size is exceeded.	-102
ERROR_ENCODE_FAILED	Error occurred in encoding text data.* ¹	-111
ERROR_TIMEOUT	Send timeout occurred.	-201
	Receive timeout occurred.	
ERROR_FILE_NOT_FOUND	Specified file is not found.	-301
ERROR_FILE_USED	Specified file is being used by another process.	-302
ERROR_FILE_INVALID	Specified file is invalid.	-303
ERROR_LOW_MEMORY	Insufficient memory occurred when loading image file.	-311
ERROR_OVER_MAX_IMAGE	Either or both of width and height of image file exceeds the number of printable maximum dots.	-312
ERROR_LOGO_NOT_DEFINED	Logo is not registered.	-313
ERROR_LOW_USER_AREA	Remaining user area is insufficient.	-401
ERROR_LOW_EXTERNAL_RAM	Remaining RAM capacity is insufficient.	-402
ERROR_PAGE_MODE_SPECIFIED	Page mode is specified.	-511

Constant Name	Description	Value
ERROR_PAGE_MODE_NOT_SPECIFIED	Page mode is not specified.	-512
ERROR_INVALID_PARAM	Specified parameter is invalid.	-9999

*1: Abnormal processing might have occurred.

(3) Method Details

PrinterException

Constructor

Constructor for the **com.seikoinstruments.sdk.thermalprinter.PrinterException** class.

Syntax `public PrinterException(int code, String message)`

getErrorCode

Get error codes

Gets the error code for thrown exception.

Syntax `public int getErrorCode()`

Return value See "4.2.5(2) Constant List" for details of the error.

4.2.6 CallbackFunctionListener Interface

CallbackFunctionListener Interface is an interface for getting the change event of printer status.

(1) Method List

Method of **CallbackFunctionListener** Interface is shown below.

Name	Description
onStatusChanged	Change event of printer status

(2) Method Details

onStatusChanged	Change event of printer status
------------------------	--------------------------------

Syntax `public void onStatusChanged(int status)`

Parameter *status* Printer status

Description This method is called at the following timing.
 ·When **setCallbackFunctionListener** is executed.
 ·When the printer status is changed.

The change event of printer status is notified when **isConnect** is true.

This method is an interface, so it is not implemented.

Implement the optional process in the class that receives a callback of the printer status change.

Do not execute the APIs of **PrinterManager** within this method.

4.2.7 BarcodeScannerListener Interface

BarcodeScannerListener Interface is an interface for the barcode scanner connection, barcode scanner disconnection, or received barcode data obtaining.

MP-B30/MP-B30L does not support this interface.

Chapter 5

Sample Program

This chapter describes the sample program provided by SII print class library.

SII print class library includes the sample program in Android Studio project format.


5.1 Installation

Install the sample program.


Ensure that the environment for developing Android application is prepared. See "Chapter 3 How to Use the Library" for details about required development environment.

The procedures are shown below.


- (1) Place a sample folder at any location.
- (2) Start Android Studio, and click "Open an existing Android Studio project".




(3) Select the folder placed in the step (1), and click [OK].



(4) Click [Run 'app'].




(5) Select the device, and click [OK].




5.2 Screen Layout

This section describes the screen of the sample program.


5.2.1 Main screen



Item	Description
Connection type	Selects connection form to a printer.
Address	Specifies the printer address. For manual input: When connecting with Bluetooth, enter the Bluetooth address. When connecting with TCP/IP, enter the MAC address. For automatic input: By tapping the [List] button, the information of printers found by startDiscoveryPrinter(Bluetooth) is displayed in a list. When selecting a printer from the displayed list, the Bluetooth address is automatically entered.
Method Button	The buttons for executing each method. When scrolling, it is possible to see the methods and properties that are not displayed. See "Chapter 4 Functions of the Library" for details of each method.
SETTINGS	Tapping the [SETTINGS] button opens the function setting screen. In order to go back to the main screen, tap  on the screen.
Log	Executing each method of "Method Button", displays the method execution logs.

5.2.2 [SETTINGS] screen

Various setting functions are displayed in [SETTINGS].



5.3 Precaution

The sample program is subject to change without notice.

No guarantee of proper operation and support are provided for the sample program.

Appendix A

Character Set

A.1 Codepage Table (Character Code Table)

The codepages when **COUNTRY_USA** is set for the international character set are shown below. Print results of the specific character codes vary depending on the setting of the international character set. See "A.2 International Character Set" for the specific character codes.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	φ	£	¥	℔	ƒ
A0	á	í	ó	ú	ñ	Ñ	ä	ö	¿	¬	½	¼	¿	»	«	»
B0	☐	☐	☐		†	‡	§	¶	§	¶	§	¶	§	¶	§	¶
C0	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ
D0	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ	ℒ
E0	α	β	Γ	π	Σ	σ	μ	τ	φ	θ	Ω	δ	∞	φ	ε	Π
F0	≡	±	≥	≤	∫	∫	÷	≈	°	•	•	√	n	2	■	■

Figure A-1 CODE_PAGE_437 (USA, Standard Europe)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80																
90																
A0	。	「	」	、	・	ヲ	ア	イ	ウ	エ	オ	ヤ	ユ	ヨ	ッ	
B0	ー	ア	イ	ウ	エ	オ	カ	キ	ク	ケ	コ	サ	シ	ス	セ	ソ
C0	タ	チ	ツ	テ	ト	ナ	ニ	ヌ	ネ	ノ	ハ	ヒ	フ	ヘ	ホ	マ
D0	ミ	ム	メ	モ	ヤ	ユ	ヨ	ラ	リ	ル	レ	ロ	ワ	ン	ゝ	。
E0																
F0																

Figure A-2 CODE_PAGE_KATAKANA

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	à	â	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	ø	£	Ø	×	f
A0	á	í	ó	ú	ñ	Ñ	ä	ö	¿	®	¬	½	¼	¡	«	»
B0	☐	☐	☐			Á	Â	À	©	¶	¶	¶	¶	¢	¥	₱
C0	⊥	⊥	⊥	⊥	⊥	ã	Ã	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	α
D0	ð	Đ	Ê	Ë	È	Í	Î	Ï	⌋	⌋	■	■	■	■	■	■
E0	ó	β	ô	ò	õ	õ	μ	þ	þ	ú	û	ù	ý	ý	-	'
F0	-	±	=	¾	¶	§	÷	,	°	…	.	¹	³	²	■	

Figure A-3 CODE_PAGE_850 (Multilingual)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ã	à	Á	ç	ê	Ê	è	Í	Ô	ì	Ã	Â
90	É	À	È	ô	õ	ò	Ú	ù	Ì	Õ	Ü	¢	£	Ù	Þ	Ó
A0	á	í	ó	ú	ñ	Ñ	ä	ö	ï	ò	¬	½	¼	¡	«	»
B0	⌠	⌡	⌢	⌣	⌤	⌥	⌦	⌧	⌨	〈	〉	⌫	⌬	⌭	⌮	⌯
C0	⌰	⌱	⌲	⌳	⌴	⌵	⌶	⌷	⌸	⌹	⌺	⌻	⌼	⌽	⌿	⌿
D0	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿
E0	α	β	Γ	π	Σ	σ	μ	τ	φ	θ	Ω	δ	∞	φ	ε	Π
F0	≡	±	≥	≤	∫	∫	÷	≈	°	•	•	√	n	2	■	

Figure A-4 CODE_PAGE_860 (Portuguese)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	À	à	¶	ç	ê	ë	è	ï	î	≡	À	§
90	É	È	Ê	ô	Ë	Ï	Ô	Ù	⌘	Ô	Ü	¢	£	Ù	Ù	f
A0	¡	´	ó	ú	¨	³	-	î	¬	¬	½	¼	¾	«	»	
B0	⌠	⌡	⌢	⌣	⌤	⌥	⌦	⌧	⌨	〈	〉	⌫	⌬	⌭	⌮	⌯
C0	⌰	⌱	⌲	⌳	⌴	⌵	⌶	⌷	⌸	⌹	⌺	⌻	⌼	⌽	⌿	⌿
D0	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿	⌿
E0	α	β	Γ	π	Σ	σ	μ	τ	φ	θ	Ω	δ	∞	φ	ε	Π
F0	≡	±	≥	≤	∫	∫	÷	≈	°	•	•	√	n	2	■	

Figure A-5 CODE_PAGE_863 (Canadian-French)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	ø	£	Ø	Pt	f
A0	á	í	ó	ú	ñ	Ñ	ä	ö	¿	¬	½	¼	¡	«	»	
B0	☐	☐	☐		†	‡	§	¶	§		¶		¶		¶	
C0	L	⊥	T	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥
D0	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥
E0	α	β	Γ	π	Σ	σ	μ	τ	φ	θ	Ω	δ	∞	φ	ε	Π
F0	≡	±	≥	≤		J	÷	≈	°	.	.	√	n	2	■	

Figure A-6 CODE_PAGE_865 (Nordic)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	ø	£	Ø	Ş	ş
A0	á	í	ó	ú	ñ	Ñ	Ğ	ğ	¿	®	¬	½	¼	¡	«	»
B0	☐	☐	☐		†	‡	§	¶	§		¶		¶		¶	
C0	L	⊥	T	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥
D0	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥	⊥
E0	ó	β	ô	ò	õ	õ	μ	×	ú	û	ü	ì	ÿ	-	'	
F0	-	±	¾	¶	§	÷	.	°	..	.	1	3	2	■		

Figure A-7 CODE_PAGE_857 (Turkish)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Α	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο	Π
90	Ρ	Σ	Τ	Υ	Φ	Χ	Ψ	Ω	α	β	γ	δ	ε	ζ	η	θ
A0	ι	κ	λ	μ	ν	ξ	ο	π	ρ	σ	ς	τ	υ	φ	χ	ψ
B0	⋈	⋈	⋈		†	‡		π	‡			π				
C0	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈
D0	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈	⋈
E0	ω	ά	έ	ή	ϊ	ί	ό	ύ	ϋ	ώ	Ά	Έ	Ή	Ί	Ό	Υ
F0	Ω	±	≥	≤	İ	ÿ	÷	≈	°	•	•	√	n	2	■	

Figure A-8 CODE_PAGE_737 (Greek)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	€	‚	ƒ	„	…	†	‡	^	‰	Š	<	Œ		Ž		
90		‘	’	“	”	•	-	-	~	™	š	>	œ		ž	ÿ
A0		ı	¢	£	¤	¥	¦	§	¨	©	ª	«	¬	®	¯	
B0	°	±	²	³	´	µ	¶	·		¹	º	»	¼	½	¾	¿
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F0	ð	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ

Figure A-9 CODE_PAGE_1252 (Latin)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	А	Б	В	Г	Д	Е	Ж	З	И	Й	К	Л	М	Н	О	П
90	Р	С	Т	У	Ф	Х	Ц	Ч	Ш	Щ	Ъ	Ы	Ь	Э	Ю	Я
A0	а	б	в	г	д	е	ж	з	и	й	к	л	м	н	о	п
B0	␣	␣	␣		†	‡	§	¶	‡	§	¶	‡	§	¶	‡	§
C0	␣	␣	␣		†	‡	§	¶	‡	§	¶	␣	␣	␣	␣	␣
D0	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
E0	р	с	т	у	ф	х	ц	ч	ш	щ	ъ	ы	ь	э	ю	я
F0	Ё	ё	Є	є	İ	ı	Ÿ	ÿ	°	•	•	√	№	α	■	

Figure A-10 CODE_PAGE_866 (Russian)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	û	ç	ł	ë	ő	ö	î	ž	Ä	Ć	
90	É	Í	í	ô	ö	Ł	ł	Ś	ś	Ö	Ü	Ť	ť	Ł	×	č
A0	á	í	ó	ú	À	à	Ž	ž	Ę	ę	¬	ž	Č	š	«	»
B0	␣	␣	␣		†	‡	§	¶	‡	§	¶	␣	␣	␣	␣	␣
C0	␣	␣	␣		†	‡	§	¶	‡	§	¶	␣	␣	␣	␣	␣
D0	đ	Đ	Ď	Ě	ď	Ň	í	î	ě	Ĵ	Ĵ	■	■	Ť	Ů	■
E0	ó	ß	ô	ń	ň	š	š	ř	ú	ř	ů	ý	ý	ť	´	
F0	-	"	˘	˘	˘	§	÷	˘	˘	˘	˘	Ů	Ř	ř	■	

Figure A-11 CODE_PAGE_852 (Eastern Europe)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	Ç	ü	é	â	ä	à	â	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	ø	£	Ø	×	ƒ
A0	á	í	ó	ú	ñ	Ñ	ä	ö	¿	®	¬	½	¼	¡	«	»
B0	⌘	⌘	⌘			Á	Â	À	©	⌘	⌘	⌘	⌘	⌘	⌘	⌘
C0	L	L	T	T	T	ã	Ã	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	α
D0	ð	Ð	Ê	Ë	È	€	Í	Î	Ï	Ј	Г	■	■	І	İ	■
E0	ó	β	ô	ò	õ	õ	μ	þ	þ	ú	û	ü	ý	ý	-	'
F0	-	±	=	¾	¶	§	÷	,	°	…	.	1	3	2		■

Figure A-12 CODE_PAGE_858 (Euro)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	ђ	Ђ	ѓ	Ѓ	ё	Ё	є	Є	ѕ	Ѕ	і	І	ї	Ї	ј	Ј
90	љ	Љ	њ	Њ	ћ	Ћ	ќ	Ќ	џ	Џ	џ	џ	џ	џ	џ	џ
A0	а	А	б	Б	в	В	г	Г	д	Д	е	Е	ф	Ф	г	Г
B0	⌘	⌘	⌘			х	Х	и	И	⌘	⌘	⌘	⌘	⌘	⌘	⌘
C0	L	L	T	T	T	к	К	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	ℓ	α
D0	л	Л	м	М	н	Н	о	О	п	П	г	■	■	П	я	■
E0	Я	р	Р	с	С	т	Т	у	У	ж	Ж	в	В	ь	ь	№
F0	-	ы	Ы	э	Э	ш	Ш	э	Э	щ	Щ	ч	Ч	§		■

Figure A-13 CODE_PAGE_855 (Cyrillic)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	°	•	•	√	■	-		+	+	+	+	+	+	+	+	+
90	β	∞	φ	±	½	¼	≈	«	»	لأ	لأ					لا
A0	-	£	£	£	£			ل	ب	ث	ج	ح	خ	ح	خ	خ
B0	•	١	٢	٣	٤	٥	٦	٧	٨	٩	ف	س	ش	ص	ش	؟
C0	φ	ء	آ	أ	ؤ	ع	ئ	ب	ة	ث	ت	ج	د	خ	د	د
D0	ذ	ر	ز	س	ش	ص	ض	ط	ظ	ع	غ		÷	×	ع	ع
E0	-	ف	ق	ك	ل	م	ن	ه	و	ي	ض	ع	غ	غ	غ	م
F0	-	”	ن	ه	ه	ي	ي	غ	ي	غ	ي	غ	ي	غ	ي	■

Figure A-14 CODE_PAGE_864 (Arabic)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	€	‘	’	“	”	…	†	‡	‰	Š	<	Š	Ť	Ž	Ž	
90		‘	’	“	”	•	-	-	™	š	>	š	ť	ž	ž	
A0	˘	˘	Ł	Ł	Ą		Ś	..	©	§	«	¬	-	®	Ž	
B0	°	±	ł	ł	μ	¶	•	ą	§	»	Ł	”	ł	ž	ž	
C0	Ř	Á	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā	Ā
D0	Đ	Ň	Ň	Ó	Ô	Õ	Ö	×	Ř	Ů	Ú	Ú	Ú	Ú	Ý	Ť
E0	ř	á	â	ä	ä	í	ć	ç	č	é	ę	ě	ě	í	î	ď
F0	đ	ň	ň	ó	ô	õ	ö	÷	ř	ů	ú	ú	ú	ú	ý	ť

Figure A-15 CODE_PAGE_1250 (Central European)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	ђ	ѓ	;	ѓ	„	...	†	‡	€	‰	Љ	<	Њ	ќ	ћ	џ
90	ђ	‘	;	“	”	•	-	-	™	Љ	>	њ	ќ	ћ	џ	
A0	ÿ	ÿ	Ј	Ѡ	Г	І	Ѕ	Ё	©	Є	«	¬	-	®	İ	
B0	°	±	І	і	г	μ	¶	•	ё	№	є	»	ј	Ѕ	ѕ	ї
C0	А	Б	В	Г	Д	Е	Ж	З	И	Й	К	Л	М	Н	О	П
D0	Р	С	Т	У	Ф	Х	Ц	Ч	Ш	Щ	Ъ	Ы	Ь	Э	Ю	Я
E0	а	б	в	г	д	е	ж	з	и	й	к	л	м	н	о	п
F0	р	с	т	у	ф	х	ц	ч	ш	щ	ъ	ы	ь	э	ю	я

Figure A-16 CODE_PAGE_1251 (Cyrillic)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	€	‘	;	ƒ	„	...	†	‡	‰		<					
90		‘	;	“	”	•	-	-	™		>					
A0	ˆ	Â	£	¤	¥	¦	§	¨	©	ª	«	¬	-	®	¯	
B0	°	±	²	³	´	μ	¶	·	¸	¹	º	»	¼	½	¾	¸
C0	ı	Α	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο
D0	Π	Ρ		Σ	Τ	Υ	Φ	Χ	Ψ	Ω	İ	ÿ	ά	έ	ή	ί
E0	ύ	α	β	γ	δ	ε	ζ	η	θ	ι	κ	λ	μ	ν	ξ	ο
F0	π	ρ	ς	σ	τ	υ	φ	χ	ψ	ω	ï	ÿ	ό	ύ	ώ	

Figure A-17 CODE_PAGE_1253 (Greek)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	
80	€	‘	’	“	”	…	†	‡	^	‰	Š	<	Œ			
90		‚	‚	„	„	•	-	-	~	™	š	>	œ			ÿ
A0	ı	¢	£	¤	¥	¦	§	¨	©	ª	«	¬	®	¯		
B0	°	±	²	³	´	µ	¶	·	¸	¹	º	»	¼	½	¾	¿
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0	Ğ	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	İ	Ş	ß
E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F0	ğ	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ı	ş	ÿ

Figure A-18 CODE_PAGE_1254 (Turkish)

A.2 International Character Set

Print results of the specific character codes vary depending on the setting of the international character set.

The following table shows the specific character codes and their print results.

	23	24	40	5B	5C	5D	5E	60	7B	7C	7D	7E
COUNTRY_USA	#	\$	@	[\]	^	`	{		}	~
COUNTRY_FRANCE	#	\$	à	°	ç	§	^	`	é	ù	è	..
COUNTRY_GERMANY	#	\$	§	Ä	Ö	Ü	^	`	ä	ö	ü	ß
COUNTRY_ENGLAND	£	\$	@	[\]	^	`	{		}	~
COUNTRY_DENMARK_1	#	\$	@	Æ	Ø	Å	^	`	æ	ø	å	~
COUNTRY_SWEDEN	#	α	É	Ä	Ö	Å	Ü	é	ä	ö	å	ü
COUNTRY_ITALY	#	\$	@	°	\	é	^	ù	à	ò	è	ì
COUNTRY_SPAIN	ℙ	\$	@	ı	Ñ	ı	^	`	..	ñ	}	~
COUNTRY_JAPAN	#	\$	@	[¥]	^	`	{		}	~
COUNTRY_NORWAY	#	α	É	Æ	Ø	Å	Ü	é	æ	ø	å	ü
COUNTRY_DENMARK_2	#	\$	É	Æ	Ø	Å	Ü	é	æ	ø	å	ü
COUNTRY_SPAIN_2	#	\$	á	ı	Ñ	ı	é	`	í	ñ	ó	ú
COUNTRY_LATIN_AMERICA	#	\$	á	ı	Ñ	ı	é	ü	í	ñ	ó	ú
COUNTRY_ARABIA	#	\$	@	[\]	^	`	{		}	~

Figure A-19 International Character Set



Seiko Instruments Inc.
1-8, Nakase, Mihama-ku, Chiba-shi,
Chiba 261-8507, Japan
Print System Division
Telephone:+81-43-211-1106
Facsimile:+81-43-211-8037

Seiko Instruments USA Inc.
Thermal Printer Div.
21221 S. Western Avenue, Suite 250, Torrance, CA 90501, USA
Telephone:+1-310-517-7778 Facsimile:+1-310-517-7779

Seiko Instruments GmbH
Siemensstrasse 9, D-63263 Neu-Isenburg, Germany
Telephone:+49-6102-297-0 Facsimile:+49-6102-297-222
info@seiko-instruments.de

Seiko Instruments (H.K.) Ltd.
4-5/F, Wyler Center 2,200 Tai Lin Pai Road, Kwai Chung, N.T., Kowloon, Hong Kong
Telephone:+852-2494-5160 Facsimile:+852-2424-0901

(Specifications are subject to change without notice.)